




**- INSTALLATION GUIDE -  
"MS" MODEL CASH DRAWER**

**Instructions for attaching "MS" model cash drawers under counter:**

**Note: Keys and all required mounting hardware are taped to the underside of the cash drawer.**

First remove the drawer from the case. It will be necessary to release the drawer slides so that the drawer can be removed from the case. The slides are released by pressing in on the black slide release levers found on each side of the drawer (see FIG. 1). While pressing in on the release levers on both sides of the drawer, pull the drawer out from the case. It may be necessary to hold the case in place, while pulling the drawer out of the case.



To reinstall the drawer, align the drawer slide channels with the case slide channels and SLOWLY push the drawer into the case. The drawer should insert freely into the case without excessive force. If excessive force is required to install the drawer, check the alignment of the case and drawer channels before proceeding any further

Once the drawer is removed from the case, follow the instructions below for mounting the cash drawer under the counter.

1. When mounting the cash drawer case to the counter, please take into consideration that the unit must be mounted to a flat surface. If the case is not mounted to a flat surface, the case will be deformed and the drawer will not function properly.
2. Position the case under the counter in the desired location and mark the locations of the eight (8) mounting holes (see FIG. 2).
3. Drill a small pilot hole at each of the locations marked above, and attach the case to the counter using the screws provided.
4. Make sure the screws are adequately tightened, but take care not to strip the screws.
5. Following the directions above, reinstall the drawer into the case once the case is mounted under the counter.

