



## The Clinton Nightstand




## The Clinton Nightstand

 Step 1
 Lay the nightstand flat on a protected surface with the underside facing up.




Step 2 Rest the legs on top of the corresponding pre-drilled holes.




## The Clinton Nightstand

Step 3 To secure the legs, place the screws into the pre-drilled holes and tighten them using the Allen key. Take care not to strip the screws.



Step 4 Take a moment to confirm the hardware is secured tightly at all connection points.



Step 5With the help of another person,<br/>carefully flip the nightstand over.

