




Black & Vintage Brown Wood Electric Desk

Instruction Manual



SKU: DESK-E144BN



Scan the QR code with your mobile device or follow the link for helpful videos and specifications related to this product.

<https://vivo-us.com/products/desk-e144bn>

GET IN TOUCH | Monday-Friday from 7:00am-7:00pm CST



help@vivo-us.com



www.vivo-us.com
Chat live with an agent!



309-278-5303



WARNING!

If you do not understand these directions, or if you have any doubts about the safety of the installation, please call a qualified technician. Check carefully to make sure there are no missing or defective parts. Improper installation may cause damage or serious injury. Do not use this product for any purpose that is not explicitly specified in this manual and do not exceed weight capacity. We cannot be liable for damage or injury caused by improper mounting, incorrect assembly, or inappropriate use.

ELECTRICAL SAFETY INSTRUCTIONS


THIS PRODUCT IS POWERED BY ELECTRICITY. IN ORDER TO AVOID BURNS, FIRE AND ELECTRIC SHOCK, PLEASE READ THE FOLLOWING INSTRUCTIONS CAREFULLY.

- DO NOT CLEAN PRODUCT WHILE POWER IS CONNECTED.
- DO NOT DISASSEMBLE OR REPLACE COMPONENTS WHILE POWER IS CONNECTED.
- NEVER OPERATE THE SYSTEM WITH A DAMAGED CORD OR PLUG. PLEASE CONTACT YOUR SELLER TO REPLACE DAMAGED PARTS.
- NEVER OPERATE SYSTEM IN DAMP ENVIRONMENTS OR IF ANY ELECTRICAL COMPONENTS HAVE MADE CONTACT WITH LIQUIDS.
- ALTERATIONS OF THE GIVEN POWER UNIT ARE NOT ALLOWED.
- OUTDOOR USE IS PROHIBITED.

WARNING: CHOKING HAZARD

SMALL PARTS - NOT FOR CHILDREN UNDER 3 YEARS. ADULT SUPERVISION IS REQUIRED.

PACKAGE CONTENTS




A (x1)
Desktop



B (x1)
Left Crossbar




C (x1)
Right Crossbar



D (x2)
Side Brackets



E (x2)
Foot




F (x2)
Sync Rod



G (x1)
Connecting
Bracket




H (x1)
Leg



I (x1)
Motorized Leg



J (x1)
Control Panel



K (x1)
AC Adapter



L (x2)
Cable Clips



M (x17)
Anti-Vibration
Pads



N (x2)
Headphone
Hook



O (x4)
Rectangle
Connector



P (x2)
Square
Connector




S-A (x14)
M6x11mm
Screw



S-B (x39)
M5x16mm
Screws



S-C (x8)
M6x35mm
Screws



S-D (x14)
Wooden
Dowels



T-A (x1)
2mm Allen
Wrench



T-B (x1)
5mm Allen
Wrench

TOOLS NEEDED



Phillips
Screwdriver

DO NOT EXCEED WEIGHT CAPACITY.


Failure to do so may result in serious injury.

154lbs
(70kg)

ASSEMBLY STEPS


STEP 1

Attach Left Crossbar (**B**) to Leg (**H**) using M6x11mm Screws (**S-A**) and 5mm Allen Wrench (**T-B**). Connect Right Crossbar (**C**) to Motorized Leg (**I**) using M6x11mm Screws (**S-A**) and 5mm Allen Wrench (**T-B**).




STEP 2

Connect Side Brackets (**D**) to Motorized Leg (**I**) and Leg (**H**) using M6x11mm Screws (**S-A**) and 5mm Allen Wrench (**T-B**).




STEP 3

Attach Foot (E) to Leg (H) and Motorized Leg (I) using M6x35mm Screws (S-C) and 5mm Allen Wrench (T-B).




STEP 4

Use Connecting Bracket (G) to join leg assemblies together by securing it over Left Crossbar (B) and Right Crossbar (C) using M6x11mm Screws (S-A) and 5mm Allen Wrench (T-B).




STEP 5

Loosen the knob on the Sync Rod (**F**) and extend the hex shaft. Insert hex shaft into the Leg (**H**), making sure the metal retaining ring makes contact with the Leg (**H**). While holding the hex shaft with one hand, extend Sync Rod (**F**) onto the spline shaft of Motorized Leg (**I**). Tighten Sync Rod (**F**) using 2mm Allen Wrench (**T-A**). Retighten knob. Apply Anti-Vibration Pads (**M**) to top of frame assembly.



STEP 6

Place Wooden Dowels (**S-D**) into pre-drilled holes in Desktop (**A**) pieces, then slide together to form one desktop piece, as shown below. *[Desktop pieces are labeled 1 thru 4 and should be assembled as shown below]*



STEP 6 (Continued)


Secure desktop assembly using Rectangle and Square Connectors (**O**, **P**), M5x16mm Screws (**S-B**), and a Phillips screwdriver. *Desktop p*

STEP 7

Flip frame assembly over and secure to assembled Desktop (**A**) using M5x16mm Screws (**S-B**) and a Phillips screwdriver. Screws will be installed into Side Brackets (**D**) and Connecting Bracket (**G**). Attach Headphone Hook (**N**) and Controller (**J**) to Desktop (**A**) using M6x16mm Screws (**S-C**) and a Phillips screwdriver.

STEP 8


Connect cable from Motorized Leg (I) to Control Panel (J), as shown below. Connect AC Adapter (K) to Control Panel (J). Secure cables to Desktop (A) using Cable Clips (L).



CAUTION!



Do not exceed desk weight limit.



Keep area of vertical motion free of obstacles.



Keep weight on desk balanced for correct operation and longer life of components.



Leave enough slack in cables to allow for full range of vertical motion.

Failure to follow these instructions may result in property damage and/or personal injury.



Open **Monday - Friday 7:00am - 7:00pm CST**,
our dedicated support team can offer immediate assistance with rapid response times. If any
parts are received damaged or defective, please contact us. We are happy to replace parts to
ensure you have a fully functioning product.

 309-278-5303 **AVG. RESOLUTION TIME** *(within office hrs):* **5M 4S**

 www.vivo-us.com **AVG. RESOLUTION TIME** *(within office hrs):* **< 15 M**
Chat live with an agent!

 help@vivo-us.com **AVG. RESPONSE TIME** *(within office hrs):* **1HR 8M**
- 23% within < 15m
- 38% within < 30m
- 61% within < 1hr
- 83% within < 2hr
- 92% within < 3hr