CAROLINA
GYM SUPPLY CORP.

575 Dimmocks Mill Rd, Hillsborough NC 27278
www.carolinagym.com   info@carolinagym.com
(919) 732-6999   fax (919) 732-1510
Toll Free: 877-G$_4$Y$_9$M$_6$-S$_7$T$_8$U$_8$F$_3$

Vault Board Recovery Kit Instructions

Your Vault Recovery Kit includes:
1 – Can of Spray Adhesive
1 – Carpet Replacement
1 – Beveled Foam Replacement

You will also need:
A marker
A tape measure/ruler
Staple gun

How To:

1. Remove old carpet and foam by removing the staples.
2. Clean vault board surface thoroughly to ensure that adhesive will stick properly.
3. Using your tape measure/ruler, make a visible mark 1" from the front and sides, and 3" from the bottom of the board. This is where your foam will go.
4. Follow instructions on glue can and spray both the back/bottom of the foam and the springboard. As this glue is a variation of contact cement, you must wait for the glue to set (approx. 4 mins) on both the foam and wood before you put them together. When the glue feels sticky to the touch, it is time to put the two pieces together. Make sure your foam is placed within your marks.
5. Before gluing, make sure to lay your carpet on top of the board and understand how you will have to place it. There will be an overlap of carpet. This will be stapled down later. The most important thing to remember is that you will need the most overlap at the front of the board.
6. Follow the same glue instructions, this time spraying the top of the foam and the underside of the carpet. Wait for the glue to become tacky to the touch.
7. Starting from the back of your board slowly lay the carpet on top of the foam, smoothing out as you go.
8. Staple the carpet to the board (also starting from the back) as you see fit.

As always, please feel free to call us toll free at 877-496-7883 if you have any questions regarding this process. Thank you for choosing Carolina Gym Supply for your gymnastics needs!!