



DRAW LINES WHERE YOU WANT WELDED UPPER LOOP CROSSBARS LOCATED WITH A DISTANCE FROM THE BACK OF THE RACK. INDICATE MODEL, DIMENSIONS AND DESIRED LOCATIONS OF SOLAR PANELS TO ENSURE FITMENT.

DRAW SQUARES WHERE VENTS AND AC UNITS ARE PRESENT. INCLUDE A LENGTH AND WIDTH OF VENTS AND AC UNITS, AS WELL AS THE DISTANCE FROM THE REAR OF THE VENT/AC TO THE CENTER OF THE REAR (SMALL) PLUG INDICATED ON THE DRAWING. IF THE VENT/AC IS NOT CENTERED ON YOUR ROOF, PROVIDE THE DISTANCE FROM ONE SIDE OF THE VENT/AC TO THE CENTER OF THE TRACK ON THAT SIDE, IN ADDITION TO THE OTHER MEASUREMENTS.

BUILD NOTES:



VEHICLE:

**SPRINTER 170 EB
TALL ROOF**

EDGE TILT			
	FRONT	SIDES	BACK
DBL. LOOP	1 1/2"	1 5/16"	11/16"
TOURING	N/A	0"	0"

SIZE
A

DWG:

Sprinter 170 EB Tall Roof

SCALE: 1:22

SHEET 1 OF 1