



DRAW LINES WHERE YOU WANT WELDED UPPER LOOP CROSSBARS LOCATED WITH A DISTANCE FROM THE BACK OF THE RACK. INDICATE MODEL, DIMENSIONS AND DESIRED LOCATIONS OF SOLAR PANELS TO ENSURE FITMENT.

DRAW SQUARES WHERE VENTS AND AC UNITS ARE PRESENT. INCLUDE A LENGTH AND WIDTH OF VENTS AND AC UNITS, AS WELL AS THE LOCATION OF THE VENT/AC GIVEN BY A MEASUREMENT FROM THE REAR OF THE UNIT TO THE CENTER OF ONE OF THE FIVE MOUNTING LOCATIONS SHOWN. IF THE VENT/AC IS NOT CENTERED ON YOUR ROOF, ALSO PROVIDE THE DISTANCE FROM ONE SIDE OF THE VENT/AC TO THE CENTER OF THE MOUNTING LOCATIONS ON THAT SIDE.

**BUILD NOTES:**



VEHICLE:

**TRANSIT 148 EB  
TALL ROOF**

EDGE TILT			
	FRONT	SIDES	BACK
DBL. LOOP	1 1/2"	1 5/16"	11/16"
TOURING	N/A	0"	0"

SIZE  
**A**

DWG:

Transit 148 EB Tall Roof

SCALE: 1:21

SHEET 1 OF 1