



#10600 • BUNGEE ROPE

The Chase Harper Bungee Rope is an adjustable 4-point method for securing a small load to either the motorcycle seat or to mounts on either a tail trunk or saddle bags (those equipped with mounting loops or D-rings). As each situation is inherently different, there are several ways to secure each particular load; mainly criss-cross or 1) front to 2) back to 3) back to 4) front (there are 4 hooks to attach). Both the free end and interior load hooks are usually both adjusted depending on the situation. When making final adjustments, make sure that the free end of the Bungee Rope extends AT LEAST 1.5" beyond the hook.

See below examples. The instructions for adjusting the Bungee Hooks are at bottom of page.



ADJUSTING the BUNGEE ROPE HOOKS



A. With your load in place, simply put the Free End through the top of the hook and pass it behind the hook (as shown by the arrows in the illustration).

Bring the Free End back up through the top of the hook (again as shown in the illustration).

End

Position the hook about 1" above where you plan to affix it on the motorcycle and hook it. Adjust the fit at this point.

When it is fitted to your satisfaction, pull the load end tight.



CHASE HARPER USA




#10600 • BUNGEE ROPE

The Chase Harper Bungee Rope is an adjustable 4-point method for securing a small load to either the motorcycle seat or to mounts on either a tail trunk or saddle bags (those equipped with mounting loops or D-rings). As each situation is inherently different, there are several ways to secure each particular load; mainly criss-cross or 1) front to 2) back to 3) back to 4) front (there are 4 hooks to attach). Both the free end and interior load hooks are usually both adjusted depending on the situation. When making final adjustments, make sure that the free end of the Bungee Rope extends AT LEAST 1.5" beyond the hook.

See below examples. The instructions for adjusting the Bungee Hooks are at bottom of page.



ADJUSTING the BUNGEE ROPE HOOKS



A. With your load in place, simply put the Free End through the top of the hook and pass it behind the hook (as shown by the arrows in the illustration).

Bring the Free End back up through the top of the hook (again as shown in the illustration).

End

Position the hook about 1" above where you plan to affix it on the motorcycle and hook it. Adjust the fit at this point.

When it is fitted to your satisfaction, pull the load end tight.

CHASE HARPER USA

