

#5700 SLANT BAG MOUNTING INSTRUCTIONS

- With zippered compartment facing the rear, pull on rear bottom strap and slip Slant Bag over Sissy Bar.
- Adjust top strap to fit snugly around top of Sissy Bar.
- Affix side straps around rack (if applicable).
- Re-check all adjustments.
- Load Slant Bag, putting heavier items on the bottom of bag. DO NOT LOAD IN EXCESS OF 20 LBS.
- Go for a ride and have as much fun as possible.






CLEANING:

Open all zippers, remove all inserts and hardware. Hand wash using cold or warm water and a mild detergent. Hang dry.

3007 Bunsen Ave Unit F, Ventura, CA 93003 · (805) 477-9993 FAX (805) 477-9987 www. adriansports.com



#5700 SLANT BAG MOUNTING INSTRUCTIONS

- With zippered compartment facing the rear, pull on rear bottom strap and slip Slant Bag over Sissy Bar.
- 2. Adjust top strap to fit snugly around top of Sissy Bar.
- 3. Affix side straps around rack (if applicable).
- Re-check all adjustments.
- Load Slant Bag, putting heavier items on the bottom of bag. DO NOT LOAD IN EXCESS OF 20 LBS. 5.
- Go for a ride and have as much fun as possible.





CLEANING:

Open all zippers, remove all inserts and hardware. Hand wash using cold or warm water and a mild detergent. Hang dry.

3007 Bunsen Ave Unit F, Ventura, CA 93003 · (805) 477-9993 FAX (805) 477-9987 www.chaseharperusa.com

www. adriansports.com

www.chaseharperusa.com