



## SUGGESTED DAILY EMS CHECKLIST

1. Visually inspect Port O<sub>2</sub> Vent on all sides.



2. Note the position of the needle on the dial. It should be at 0, if not, adjust to 0.




3. Make sure the CPAP Adjustment Knob is all the way to the left.



4. Visually locate and identify the following:

Oxygen Hose with DISS connectors



Cylinder wrench



Long thin slot screwdriver



Extra face masks (Make sure to have one of each size, Small-Large)



Minimum two complete breathing circuits in individual packages





## SUGGESTED DAILY EMS CHECKLIST

5. Ensure that Oxygen Cylinders are close to 1,000lbs pressure.



6. Assemble the complete PortO<sub>2</sub>Vent System, inspect all fittings.



7. Pressurize the system and check for leaks.



8. Visually inspect patient exhalation valve for proper positioning of large yellow "mushroom" valve. Correct position of necessary.



Crooked Mushroom Valve

If it is not properly seated, simply remove the cap on the back of the exhalation housing where the yellow valve is seated by turning it counter-clockwise and lift slightly. DO NOT touch the mushroom valve or you may contaminate the circuit.



Twist valve cap counterclockwise



Lift valve housing slightly

Place the cap back on the housing body and twist clockwise until it locks. This will automatically re-seat the valve properly.

