
Sizes: 1200x800, 1400x800, 1600x800, 1800x800 mm

www.jasonl.com.au

### **Need help!**






Sizes: 1200x800, 1400x800, 1600x800, 1800x800 mm

#### www.jasonl.com.au

### **Need help!**

Call us on **1300 527 665** 






#### COMPONENTS

- A Table top x6
- B Leg Quadro A x2
- C Connector frame x2
- D Beam x8
- E Plastic bracket x24

#### **SCREWS**

- F M8x20MM CSK x12
- G M8x20MM Socket head x12
- H M6x20MM Socket head x24
- I M6x30MM Socket head x24




1

Sizes: 1200x800, 1400x800, 1600x800, 1800x800 mm

#### www.jasonl.com.au

#### Need help!






Using Allen Key provided, attach 2 plastic brackets per leg **(E)** (as per picture above) using M6x20MM **(H)** Socket head screw. Do the same with Connector frame **(C)**.



Using Allen Key provided, attach M8x20MM Socket head (G)-screw socket half way into leg for all legs (B) and into Connector frame (C).




Sizes: 1200x800, 1400x800, 1600x800, 1800x800 mm


#### www.jasonl.com.au

### **Need help!**





Attach beam **(D)** to legs **(B)** and Connector frame **(C)** using nut insert in legs. See point attached



Frame looks like this. Using Allen Key, attach beam (D) with Socket (F)


Sizes: 1200x800, 1400x800, 1600x800, 1800x800 mm

#### www.jasonl.com.au

### Need help!

Call us on **1300 527 665** 





desk. Nut inserts in top will align with plastic joiner brackets

using M6x30MM (I) sockets attached tops to frame.

Sizes: 1200x800, 1400x800, 1600x800, 1800x800 mm

www.jasonl.com.au


Need help!

Call us on **1300 527 665** 



TABLE TOPS BOTTOM VIEW

The following nut inserts should be used for this specific desk / workstation



Sizes: 1200x800, 1400x800, 1600x800, 1800x800 mm

www.jasonl.com.au

### Need help!



