

ASSEMBLY INSTRUCTIONS

Quadro Wood A Boardroom table


Size: 1100mm x 1100mm

www.jasonl.com.au


Need help!

Call us on
1300 527 665

jason.l
your office furniture mate



Tools Required: Power screwdriver; Allen key set (provided)

 2 persons required for installation

ASSEMBLY INSTRUCTIONS

Quadro Wood A Boardroom table


Size: 1100mm x 1100mm

www.jasonl.com.au

Need help!

Call us on
1300 527 665

jason.l
your office furniture mate




COMPONENTS

- A Table top x1
- B Leg Quadro Wood A x2
- C Beam x1 *
- D Plastic bracket x4

SCREWS

- E M8x20MM CSK x2
- F M8x20MM Socket head x2
- G M6x20MM Socket head x4
- H M6x30mm Socket head x 4
or M6x30 Wood screws x 4 and washers
- I M6x30mm Mushroom head screw x4

- J Allen key x2



* Colour of the beam is always black, regardless desk frame colour.

ASSEMBLY INSTRUCTIONS

Quadro Wood A Boardroom table

Size: 1100mm x 1100mm

www.jasonl.com.au


Need help!

Call us on
1300 527 665

jason.l
your office furniture mate




STEP 01



You will notice two colored stickers located on each leg.

Both legs must have the colour sticker facing away from where the plastic brackets are inserted.

STEP 02



Insert the bottom of the legs as shown in the illustration. Using Allen Key provided, attach Mushroom Head Screw (I) - for all legs.

ASSEMBLY INSTRUCTIONS

Quadro Wood A Boardroom table


Size: 1100mm x 1100mm

www.jasonl.com.au


Need help!

Call us on
1300 527 665


jason.l
your office furniture mate



Using Allen Key provided, attach 2 plastic brackets per leg **(D)**
(as per picture above) using M6x20MM **(G)** Socket head screw



Using Allen Key provided, attach M8x20MM Socket head **(F)**-
screw socket half way into leg for both legs **(B)**



ASSEMBLY INSTRUCTIONS

Quadro Wood A Boardroom table


Size: 1100mm x 1100mm

www.jasonl.com.au


Need help!

Call us on
1300 527 665

jason.l
your office furniture mate



Attach beam **(C)** to legs **(B)** using nut insert in legs.
See point attached



Frame looks like this. Using Allen Key, attach beam **(C)** with Socket **(E)**

ASSEMBLY INSTRUCTIONS

Quadro Wood A Boardroom table


Size: 1100mm x 1100mm

www.jasonl.com.au


Need help!

Call us on
1300 527 665

jason.l
your office furniture mate



Place desktop on top of the frame. Please place the top equally centred at the same distance from left and right of the leg frame and make sure that front and back of the top will have the same distance from the legs frame as well.



Please drill wood screws (**H**) through the plastic brackets into the underneath of the Tops.