
www.jasonl.com.au

Need help!

Call us on 1300 527 665



Sizes: 1400Lx1800W, 1600Lx1800W, 1800Lx1800W mm



Tools Required: Power screwdriver; Allen key set (provided)



2 persons required for installation


www.jasonl.com.au

Need help!

Call us on **1300 527 665**



Page 2 of 11



Sizes: 1400Lx1800W , 1600Lx1800W , 1800Lx1800W mm

First we will set up the workstation frame

without the returns

www.jasonl.com.au


Need help!

Call us on **1300 527 665**

 Γ Γ Γ







Tools Required: Power screwdriver; Allen key set (provided)




2 persons required for installation

www.jasonl.com.au


Need help!

Call us on **1300 527 665**






Using Allen Key provided, attach 4 plastic brackets (H) per leg (C) (as per picture above) using M6x20MM (L) Socket head screw. Do the same with Connector frame (E).



Using Allen Key provided, attach M8x20MM Socket head **(K)**-screw socket half way into leg for both legs **(C)** and into Connector frame **(E)**.




www.jasonl.com.au

Need help!


Call us on **1300 527 665**





Attach beam **(F)** to legs **(C)** and Connector frame **(E)** using nut insert in legs. See point attached

Frame looks like this. Using Allen Key, attach beam (F) with Socket (J)



Tools Required: Power screwdriver; Allen key set (provided)



2 persons required for installation

111


www.jasonl.com.au

Need help!

Call us on **1300 527 665**



Sizes: 1400Lx1800W, 1600Lx1800W, 1800Lx1800W mm



Now attach the return beams (G) to return legs (D) using nut insert in legs. See point attached.


Then, connect the hook of the return beam to the beam of the main structure.

www.jasonl.com.au

Need help!

Call us on **1300 527 665**






www.jasonl.com.au


Need help!

Call us on **1300 527 665**





- Place table tops (A) on top of frame with cutout at the back of the desk.
- Using nut inserts in the desk, use M6x30mm socket (M) and attach desktop to the frame.
- Using nut inserts in the desktop, use M6x30mm socket (M) and attach return desktops (B) to the frame.
- Once desktop are attached and secure to the frame, use woods screws (N) and secure joiner plates (I) to the underside of desktop A.



Floor based screen divider assembly instruction:

- Bring partition towards one another as on the picture. Using an Allen key remove top caps from the four screens uprights where they meet (circles painted in gray).
- Slide 2 way connectors rod down between the 2 centre screens and slide the 3 way 90 degree connector rod -down between the end screens.
- Under the desktops, use I-shaped panel brackets to secure the screens to the table tops (A)(B). Place two brackets in each screen.