
Care

1. Precaution and Consideration 2. Washing

When washing the outer layer. please follow instructions below:

- Machine wash, low speed, 30°C, with washing net.
- Do not wash with other laundry. otherwise color leak may occur.
- Do not bleach.
- Do not use benzine or thinner.
- Do not iron.
- Do not dry clean.
- Hang dry.
- Do not tumble drv.



3. Rinse

- Rinse thoroughly after hand wash to avoid residue of detergent.
- To avoid static electricity, please use softener after wash.

Before washing outer layer, please make sure the power bank and heater are removed. Do not wash power bank or heater.

Hand washing

- 1. Put the scarf into a suitable sized
- 2. Pour in water (below 30°C) and add
- 3. Repeatedly press the scarf when washing.

Machine wash

- 1. Put the scarf inside the washing net.
- Set water temperature below 30°C, add detergent.
- 3. Choose washing mode for polyester. Wash no longer than 10 minutes.

4. Drain/Spin and Dry

- Gently wring after hand washing to drain
- Shortly spin within 1 minute after machine
- Hang to dry in shaded place with good ventilation.

When using the heated scarf

Troubleshooting

If power bank becomes warm:

Reason: Power bank may be warm during and right after charging.

Solution: Let power bank cool down after charging.

The scarf is not warming up after connecting to the power bank:

Reason: The power bank is out of battery.

Solution: Charge the power bank.

The operating time of heated scarf is limited

Reason: The charging time is insufficient

Solution: Use the heated scarf after power bank is

fully charged.

Reason: The power bank may not be as efficient in storing electricity anymore.

Solution: Try new power bank.

If problem cannot be solved with solutions above, stop using the scarf and contact sellers for more details.

Heated Scarf HPO210GR

User Manual



www.perfectprime.com

HORMES LIMITED | Retailer

Address Telephone

Specifications

Outer Layer

Material

- Surface: Polvester Fibre 100%
- Lining & Pocket: Cotton 100%

Measurements

• 150mmX800mm

Weight

Heater

· Approx. 80g

Temperature (Skin temperature)

- Approx. 37°C~39°C or 98.6°F ~102.2°F(when surrounding
- 104°F (when surrounding
- wearing heated scarf properly. (May vary individually.)

- temperature: 10°C or 50°F)

Material

Polypropylene 100%

Measurements (Cord excluded)

- Heater: 215mm x 70mm
- Extra Heater: 220mm x 82mm

Weight

- · Heater: Approx. 15g
- Extra Heater: 18g

USB power

5V USB DC Input

- temperature: 0°C or 32°F)
- Approx. 38°C-40°C or 100.4°F ~
- * Temperature on neck when

Items included

- Scarf
- Heater
- Extra Heater
- USB Extension cord
- User manual

Assembling

- With the aid of ruler or other tools, put the heater back into the heater insertion slot.
 - There is no difference between the two sides of the heater.
- When heater is in place, remove ruler or tools used for insertion.
 - Do not fold heater during insertion.
 - Do not use the scarf if heater is not properly put back into position. This may cause low temperature burns.
- Put heater plug into cord insertion hole.
- Pull plug through the cord hole and out from the cord insertion hole near power bank pocket.

CUSTOMER SERVICE INQUIRIES

Your emails are important to us so we strive to reply all inquiries and emails within 24 hours. In exceptional cases, we may require more time to respond. Thank you for your understanding.

For more information about our products and services, please send us an email: cs@perfectprime.com

For B2B or project-based application, please send us an email: sales@perfectprime.com

FOR MORE INFORMATION ABOUT PERFECT PRIME PLEASE VISIT OUR ABOUT US PAGE AND FEEL FREE TO BROWSE.



製品マニュアルページのQRコードをスキャンする (特定の製品で利用可能な多言語)

Scan QR Code for the Product Manual page (Multi-Language available for certain products)

Overview

The heated scarf is installed with a heater so that additional heat can be provided to help you effectively combat cold weather, maintaining optimum body temperature and thus, your health. The ergonomic design of the outer layer can even further improve its ability to retain more heat, as a result you can easily stay warm.

This product is very user-friendly in that you only need to connect the heater to your own power bank, then put it around your neck to enjoy its warmth without any restriction.

The product can be utilized in many fields, for instance:



Maintain stable body temperature during winter




asic therma therapy



Relieve hypothermia when in emergency

The heated scarf is a great upgrade from traditional scarf, acting as an ideal product to add comfort to your daily life



Operation



Put connector of heater into scarf.



Pull out the connector of heater and connect it to your own power bank.



Put power bank into power bank pocket and fasten.



Wear inner layer on neck. Insert the end with power bank pocket



Adjust position of scarf.
Beware of your surrounding when using.

Safety Precautions

Please carefully read through this part before using to ensure that the product is handled correctly

To prevent any negative effects towards user or others, warnings are listed below for the sake of safety and correct usage. Based on the severity of potential harm and damage, warnings are classified into "Danger," "Warning". and "Attention". All of them are important and should be followed strictly.



DANGER

Do not get wet - Keep dry, do not use if wet. This may result in electric shock.

Do not use or keep in high temperature -Please do not place product close to fire or stove, or in the car during hot weather.



Do not swing - When plugged with power bank, do not swing the product. This may result in injuries.

Stop using if you start to feel unwell- If there is any skin irritations or ill feeling during usage, switch off the power and stop using immediately.



WARNING

- Do not use if there is an abnormal smell, heat, change of color or other abnormalities during usage or storage.
- Do not use in bath or other humid places. This may result in injuries including electric shock.
- Do not damage cords or use the scarf if cords are damaged. This may result in electric shock, heat or fire.
- Do not put into microwave ovens, other heated machines or containers with high pressure. This may result in heat, smoke or fire.
- Do not throw or apply strong force. This may damage the product.
- Give clear instructions when the product is to be used by children and keep it away from babies.
- Do not use in places where fire or explosion may occur. This may result in fire.



TTENTION

- Do not fold the heater with a strong force. Heated lines may be broken and lead to short circuit. Resulting in heat and injuries.
- Do not wear heated scarf when riding bicycles or motor bikes. This may cause injuries.
- Pay attention when using auto door, escalator or shredder.
- Do not get close to open fire when wearing heated scarf.

Low Temperature Burns

Possible Effects and Symptoms

Low temperature burns occurs when in contact with extremely high heat source.

Signs of burns such as rash or bubbles on skin may appear. However, symptoms may not always be obvious.

Prevention of Low Temperature Burns

Easiness of suffering from low temperature burns depends on individuals and how the heated scarf is used. Please pay great attention to the following:

- Stop using if the outer layer which covers the heater is broken.
- Do not use the heater without the scarf.
- Check your skin condition at least once an hour. Stop using if there is any skin irritation.
- Stop using if you feel too hot, dizzy or light headed.
- Low temperature burns may occur if used when sleeping or pressed hard against your body.
- Pay extra attention to people with medical conditions on the skin or young children and people with disabilities.
- Do not use in high temperature environments.
- Do not use if you suffer from diabetes or circulation problems.