



EHA Enhanced Hop-up Adjustment

Step by step Installation guide



1



Turn the original adjustment into the neutral position. The protruding part should be facing the Y axis.

2



Remove the hop up arms pin. Use you can use a thin screw drive to punch it through

3



Next to remove the hop-up Arm. Use the screw driver to insert into the hop-up unit, underneath the adjustment knob. Tilt your screwdriver and push up. The hop-up arm will pop out.

4



Figure 4 – Hop up arm removed.

5



Twist the adjustment knob 90 degrees to the right until it reaches the slot to be pulled out.

6



Insert the upgraded Airtech Adjustment knob into the hop-up unit.

You may keep the barrel silicone nub inside the hop-up unit.

7



Twist knob until the intruding part aligns perfectly with the pin hole. This will place the knob on the neutral position.

8



Insert the hop-up arm directly into the hop-up unit slot downwards.

9




Hold/press the hop-up arm to align the holes together enough to insert the pin into place.

10



Apply pressure to ensure the whole pin inside the pin hole

11



Install the whole hop-up unit with barrel back into the Scorpion Evo.

12



Congratulations! New hop-up gear installed!

