## **TOP** SECRET COATINGS APPLICATION INSTRUCTIONS FOR EVER-LAST EPOXY (TS-850)

This information has been prepared for use with The Ever-Last Epoxy Floor Coating System on properly prepared surfaces. Allow new concrete to cure 28 days or more before application. We recommend establishing the accurate Moisture Content (MC) of the substrate to avoid moisture related problems. The maximum MC for all surfaces is 10.0% and 4 LBS hydrostatic pressure. Recommend utilizing a properly adjusted moisture meter, VaporGuage calcium chloride moisture test, or the equivalent. Where hydrostatic pressure is found to be above 4LBS recommend using TS-104 Seal-it! Deep Penetrating Sealer. Never apply in hot direct sunlight, when humidity is above 75% or when rain is forecast within 48 hours. Most applications are by roller-coat, however brush and spray applications are acceptable. We recommend using 3/8" non-shedding roller cover on smooth surfaces, use higher nap covers on rough surfaces. All applications will require the removal of all grease, oil, glue and contaminates and the use TS-695 Etching Cleaner or an acceptable equivalent. Thoroughly scuff all existing coatings before application. When using over previously applied repair, stain or coating materials we recommend doing a test area before committing to the entire project to prevent possible compatibility issues. Recommend removing existing coatings or sealers for best results. All recommendations, written and verbal advice, these directions, label instructions and standard industry practices must be strictly adhered to or guaranty is voided.

1. PREP-WORK: All repair materials must be paintable. Sanding, grinding or blasting is always beneficial but often not required where circumstances *and* conditions permit, you must be the judge, consider carefully before proceeding. Once repair materials have cured powerwash to remove dirt and grime. Use TS-695 Etching Cleaner or the equivalent to remove contaminates and open the pores. Use TS-104 Seal-It! where hydrostatic pressure is present above 4LBS according to label directions. Allow Seal-It! to fully cure before application.

2. PRIME: Stir TS-6390 Ever-Last Epoxy Primer A&B components with a high speed mixer for two minutes. Allow to stand 10-20 minutes, stir again briefly before proceeding. Primer may be brushed, rolled or sprayed. Recommend hand brushing the edges then roll coat the remaining area. Apply evenly avoiding heavy build up. Move on to step 3 within 6–48 hours or sand between coats.

3. APPLY COLOR COAT: Two coats (clear or color) are required. Stir (TS-6433 A&B components with a high speed mixer for two minutes. Allow to stand 10-20 minutes, stir again briefly before proceeding. Hand brush the edges then roll coat the remaining area. Apply evenly avoiding heavy build up and overlaps. Allow to stand 6 hours minimum before applying next coat. Recoat within 12-48 hours. NOTE: If using chips broadcast them evenly onto the still wet surface within 5-10 minutes for best adhesion. Repeat process until entire area has been treated equally. Clear coat (step 4) is required to seal in and protect the chips.

4. APPLY TOP COAT: The second coat (clear or color) may be applied according to step 3. The second coat increases durability and chemical resistance. Let stand 24-48 hours before allowing foot traffic and minimum 96 hours before allowing motorized traffic. Warning: Too heavy clear coat application may result in unwanted amber resin color! Let stand 24 hours before allowing light foot traffic and 5-7 days before allowing motorized traffic on the new finish. Do not allow moisture on surface for 48 hours. Actual times may vary.

NOTE: Never apply to substrates exceeding 10% MC or 4 LBS hydrostatic pressure. Dry and cure time vary with temperature, ventilation, thickness of application and color. Allow extra dry and cure time for dark colors and low temperature. We hope this information helps you achieve the results you expect and years of problem free service. We are available to answer questions at 360-651-9050 M-F 9 AM to 5 PM PST. See us online at: www.topsecretcoatings.com.