

# **BLUE CAST \_ BC CR3A - For all LCD 3d printers**

# **PRODUCT FEATURES**

- Consistent casting quality as BlueCast standard
- Ash residual 0.00%
  - \_ proprietary TGA at 750°C / 4 hrs without contact to air, in closed vessel
- Low cost
- Negligible shrinkage
- No primer needed
- Monomer based resin (\*)
- High resolution
- Good strength
- Fast printing speed
- Very low odor
- Very low viscosity, no need to heat
- Chromacure® will tell you when postcure is done and pattern is ready to cast



## CONS

- Has to be managed with individual protections because of presence of monomer
- Postcuring treatment require
  - Differently from other monomer based resin that requires complex and tricky treatments our BC Crea just requires to be washed after print and cured in to BC CURING LIQUID we supply. No hot water wash required, no boiling, no overnight curing.



### **PRINTING SETTINGS**

#### **Phrozen Shuffle**

BURN IN LAYER NUMBERS OF LAYERS: 5 LAYER THICKNESS: 50u CURE TIME: 45 SEC WAIT BEFORE PRINT: 4 SEC WAIT AFTER PRINT: 0.5 SEC LIFT AFTER PRINT: 5 mm WAIT AFRER LIFT: 0.1 SEC

NORMAL LAYER LAYER THICKNESS: 50u CURE TIME: 11 SEC WAIT BEFORE PRINT: 1 SEC WAIT AFTER PRINT: 0.1 SEC LIFT AFTER PRINT: 4 mm WAIT AFRER LIFT: 0.1 SEC

MOTOR SPEED 200 u/SEC

#### **Phrozen Shuffle 4K**

BURN IN LAYER NUMBERS OF LAYERS: 5 LAYER THICKNESS: 30u CURE TIME: 30 SEC WAIT BEFORE PRINT: 5 SEC WAIT AFTER PRINT: 0.5 SEC LIFT AFTER PRINT: 7 mm WAIT AFRER LIFT: 0.1 SEC

NORMAL LAYER LAYER THICKNESS: 30u CURE TIME: 10 SEC WAIT BEFORE PRINT: 0.5 SEC WAIT AFTER PRINT: 0.1 SEC LIFT AFTER PRINT: 5 mm WAIT AFRER LIFT: 0.1 SEC

MOTOR SPEED 200 u/SEC

#### **Phrozen XL**

BURN IN LAYER NUMBERS OF LAYERS: 5 LAYER THICKNESS: 45u CURE TIME: 50 SEC WAIT BEFORE PRINT: 5 SEC WAIT AFTER PRINT: 0.5 SEC LIFT AFTER PRINT: 5 mm WAIT AFRER LIFT: 0.1 SEC



NORMAL LAYER LAYER THICKNESS: 50u CURE TIME: 9 SEC WAIT BEFORE PRINT: 1.5 SEC WAIT AFTER PRINT: 0.1 SEC LIFT AFTER PRINT: 4 mm WAIT AFRER LIFT: 0.1 SEC

MOTOR SPEED 180 u/SEC

### **ANYCUBIC PHOTON**

LAYER THICKNESS: 0.05 mm NORMAL EXPOSURE TIME: 14 SEC OFF TIME: 1 SEC BOTTOM EXPOSURE TIME: 55 SEC BOTTOM LAYERS: 5 SUPPORTS: preset medium

#### **ANYCUBIC PHOTON S**

LAYER THICKNESS: 0.05 mm NORMAL EXPOSURE TIME: 11 SEC OFF TIME: 3 SEC (don t affect the printing – it is a fake parameters on photon S) BOTTOM EXPOSURE TIME: 45 SEC BOTTOM LAYERS: 5 Z LIFT DISTANCE: 5 mm Z LIFT SPEED: 1.9 mm/S Z RETRACT SPEED: 1.9 mm/S SUPPORTS: preset medium

#### SparkMaker FHD

BURN IN LAYER NUMBERS OF LAYERS: 8 LAYER THICKNESS: 50u CURE TIME: 40 SEC WAIT BEFORE PRINT: 4 SEC WAIT AFTER PRINT: 0.5 SEC LIFT AFTER PRINT: 5 mm WAIT AFRER LIFT: 0.1 SEC

NORMAL LAYER LAYER THICKNESS: 50u CURE TIME: 14 SEC WAIT BEFORE PRINT: 1 SEC WAIT AFTER PRINT: 0.1 SEC LIFT AFTER PRINT: 5 mm WAIT AFRER LIFT: 0.1 SEC

MOTOR SPEED 200 u/SEC



### **Zortrax Inkspire**

LAYER EXPOSURE: 11 SEC BOTTOM LAYER EXPOSURE: 35 SEC EXPOSURE OFF TIME: 1.5 SEC BOTTOM LAYERS: 5 ADDITTIONAL SUPPORTS EXPOSURE: 1 SEC Z LIFT DISTANCE 5 PLATFORM SPEED 90

MOTOR SPEED 90mm/M

# **POST-PRINTING PROCESS**

Remove the prints from the build plate

Wash the prints in ethyl alcohol 90% to 99%

Dry the patterns with compressed air for best results.

Place the prints in a vessel / plastic cup

Fill the vessel with BC CURING LIQUID in order to fully submerge patterns

Place the vessel with the patterns inside at UV oven for 30 / 40 min according lamp power and patterns size

The UV cure is done when the pattern color will be BLU (ring on the right)

Wash with tapered water and dry with air

Go to cast

