

Heavy Duty Dual Bulb 72 Watt HVAC UV Air Purifier DIY Installation Instructions

Installing your HVAC germicidal system is a fairly straightforward process but the varying nature of air conditioning systems means that a little bit of judgment must be used. Still, if you follow these instructions and take the proper care, you should have cleaner, healthier air in no time.


Materials and Tools you will need:

<p>1. Drill</p>	
<p>2. 1/8" drill bit</p>	
<p>3. 3.25" diameter hole saw</p>	
<p>4. (4) #10x3/4 self-drilling screws</p>	
<p>5. Phillips screwdriver</p>	
<p>6. Adhesive tape</p>	

Installation:

At no point during the installation process should you be interacting with any electrical parts. If you wish to hardwire the system, please consult a licensed electrician.

1. Find the desired location to place your HVAC sterilization unit. The ideal location is as close to the coil as possible and is enclosed in sturdy sheet metal. Your location will vary depending on your AC system but as long as there is enough space in the vent channel to fit the light bulb and the location is as close to the coil as possible, it should be adequate.
2. Tape the included paper template to your desired location.
3. Use your 3.25" diameter hole saw to cut the large hole in the center of the template.
4. Use the 1/8" drill bit to drill the pilot holes on the 4 corners of the template. This is where your self-drilling screws will go.
5. Place the unit flush against the holes, making sure to insert the bulb into the hole in the center.
6. Insert and tighten the screws through the unit into the 4 holes that you drilled in step 4.
7. Plug the unit into 110V power (standard electrical outlet you have at your home).



That's it! If you have any questions during the installation process, please do not hesitate to reach out to us at sales@cureuv.com

Email us pictures of your installation for display on our website to receive **25% off** of your future replacement bulb purchases.