

EEZ READER[®] Y157


CHRYSLER DOUBLE-SIDED LOCK

Fits the Following Chryslers: (So Far)

All Chrysler Products 1994+


(Excluding Avenger, Sebring Coupe, and other Mitsubishi products.)

1. Prepare the lock by flushing the lock with a degreaser. Exercise the wafers by inserting blank in and out of lock several times.




2. Put *EEZ Reader*[®] together, the slide and the key tool.

3. It is recommended that you start reading from the rear of the lock and work your way out towards the face cap. It is also important to cut the key accordingly.



Remember that the door, deck and ignition locks are double-sided. You will trap and read one side and then turn the tool over and read the other side.

4. Capture a wafer in the trap slot by gently rocking the key tool back and forth to unlock the wafers from the lock case.



The wafer will usually "click" and lock into the trap slot. If the ***trap slot is***

pointing upward on the door and deck locks, you will be reading the wafers in the ***space positions of 1, 3, 5, and 7***. If the ***trap slot is pointing downward*** on the door and deck locks, you will be reading wafers in the ***space positions of 2, 4, and 6***.

5. With the wafer captured, move the slide tool towards the traps slot (tip of the key tool), very lightly, until it gently touches and stops. This means that the slide tool has come into contact with the trapped wafer. (*Note: We have found in some cases you may not be able to trap a wafer. Please remember the rule: If it will not trap, consider the depth a #1 and progress from there if necessary.*)

6. Read and record the depth.

7. Next, push the slide tool in to raise and release the trapped wafer.

8. Pull the key tool out and position it to catch the next wafer. Pull the slide tool out so the slot trap is no longer blocked.

9. Repeat the procedures 4 through 8 until you have read all the wafers. Remember to read both sides of the lock by turning over the tool. Please refer to the diagram below on wafer positions.

EEZ READER® Y157
DOUBLE-SIDED CHRYSLER

IGNITION, DOOR, AND DECK							All cuts 1 - 7
1	2	3	4	5	6	7	

Empty Boxes indicate where wafer is located.

Key Blanks:
 P1794 / Y157
 P1795 / Y159

Code Card:
 X60-CX60
 X102-CX102

Spacing	Depths
1 -- .757	
2 -- .651	1 -- .340
3 -- .573	2 -- .315
4 -- .481	3 -- .290
5 -- .389	4 -- .265
6 -- .297	
7 -- .205	

EEZ READER®

Invented and Manufactured by

T. Doyle Mc Connell

T. Doyle Mc Connell, Retired Locksmith
 With Support From the Grant Family
 Portland, Oregon

U.S. Pat. No. 4,680,870

Canadian Pat. No. 1,278,930