


# EEZ READER®

## GM10

### Fits GM J & N Body Cars


Chevrolet - Cavalier (1995+), GrandAM (1995+), Achieva (1995+),  
Sunfire (1995+), Skylark (1995+), Aurora (1995+),  
Riviera (1995+)

Fits GM Suburban and Pickups (1995+)




1. Prepare the lock by flushing the lock with a degreaser. Exercise the wafers by inserting blank in and out of lock several times.

2. Put **EEZ READER®** together, the slide and the key tool.



3. Remember that these door and deck locks are double-sided. You will trap and read one side and then turn the tool over and read the other side.

4. Capture a wafer in the trap slot by rocking the key tool back and forth to unlock the wafers.



5. When a wafer has been trapped, apply and hold slight inward pressure on the key tool. Next, move the slide tool towards the trap slot (tip of the key tool), very lightly, until it gently touches and stops. This means that the slide tool has come into contact with the trapped wafer. *(Note: We have found in some cases you may not be able to trap a wafer. Please remember this rule: If it will not trap, consider the depth #1 and progress from there if necessary.)*
6. Read and record the depth.
7. With pressure released on the key tool, push the slide tool in, to raise and release the trapped wafer.
8. Pull the key tool out and position it to catch the next wafer. Pull the slide tool out so the trap slot is no longer blocked.
9. Repeat the procedures 4 through 8 until you have read all the wafers.


Please refer to the diagrams below on wafer positions.

**GM 10 WAFER 1995/96**

- \* Ignition
- Door
- Deck (Sunfire Others)
- Deck (Cavalier)
- Glove Compartment

[illegible]

4. Capture a wafer in the trap slot by rocking the key tool back and forth to unlock the wafers.



5. When a wafer has been trapped, apply and hold slight inward pressure on the key tool. Next, move the slide tool towards the trap slot (tip of the key tool), very lightly, until it gently touches and stops. This means that the slide tool has come into contact with the trapped wafer. *(Note: We have found in some cases you may not be able to trap a wafer. Please remember this rule: If it will not trap, consider the depth #1 and progress from there if necessary.)*

6. Read and record the depth.
7. With pressure released on the key tool, push the slide tool in, to raise and release the trapped wafer.
8. Pull the key tool out and position it to catch the next wafer. Pull the slide tool out so the trap slot is no longer blocked.
9. Repeat the procedures 4 through 8 until you have read all the wafers.

Please refer to the diagrams below on wafer positions.

**GM 10 WAFER 1995/96**

- \* Ignition
- Door
- Deck (Sunfire Others)
- Deck (Cavalier)
- Glove Compartment

[illegible]

September 2009

\* The EEZ READER does not read the side-bar ignition locks.

**GM 10 WAFER 1996 1/2**

	1	2	3	4	5	6	7	8	9	10
* Ignition										
Door										
Deck										
Glove Compartment										

**Key Blanks:**

P1102 / B82 - P1106 / B86 - P1107 / B89  
B91 B102

**Code Card :**

XF215 - CF215

Spacing	Depths
1 -- 1.034	1 -- .315
2 -- .9415	2 -- .290
3 -- .8495	3 -- .265
4 -- .7575	4 -- .240
5 -- .6655	
6 -- .5730	
7 -- .4810	
8 -- .3890	
9 -- .2970	
10 -- .2045	

**EEZ READER®**

Invented and Manufactured by

*T. Doyle Mc Connell*

T. Doyle Mc Connell, Locksmith, Retired  
With the support of the Grant Family

Portland, Oregon

U.S. Pat. No. 4,680,870

Canadian Pat. No. 1,278,930