

ARSTYL® WALL PANELS


Installation instructions



Architecture & Design



ARSTYL® WALL PANELS





ARSTYL® WALL PANELS DOMINO

H 380 mm
W 1135 mm
T_{max} 38 mm

Material:

PU

 4 pces





ARSTYL® WALL PANELS ICON

H 380 mm
W 1135 mm
T_{max} 45 mm

Material:

PU

 3 pces




ARSTYL® WALL PANELS LIQUID

H 380 mm
W 1135 mm
T_{max} 28,5 mm

Material:

PU

 6 pces




ARSTYL® WALL PANELS WAVE

H 380 mm
W 1135 mm
T_{max} 18,5 mm

Material:

PU

 7 pces





ARSTYL® WALL PANELS BUMP

H 380 mm
W 1135 mm
T_{max} 43 mm

Material:

PU

 3 pces




ARSTYL® WALL PANELS CUBE

H 350 mm
W 1135 mm
T_{max} 24 mm

Material:

PU

 6 pces



INSTALLATION INSTRUCTIONS



MATERIALS REQUIRED

- Sandpaper grit 150 or finer
- Brush / sponge
- Spirit level
- Ruler and pencil
- Nail clamps or nails; wood strip, if necessary
- Hammer
- ADEFIX® PLUS assembly adhesive
- ADEFIX® adhesive filler (ceiling / wall grouting)
- Cartridge applicator
- Spacers (e.g. 1-2mm tile crosses)
- Battery screwdriver
- Spatulas
- Circular saw with guide rail
- Protective goggles
- HDPS/PU saw
- Alignment beams
- Finish coat
- Painting tools

FITTING AND STORAGE CONDITIONS:

ARSTYL® WALL PANELS must be stored flat in a dry place. The recommended temperature is +15 °C to +25°C with a relative humidity of 45% to 65%. To achieve optimum results, the products should be fitted under similar moisture and temperature conditions as present after the installation (indoor environment). Fitting on a wet backing surface (fresh plaster) and in forced drying conditions (heat gun, dehumidifier, exceptionally high temperature) are to be ruled out.

Check panels and substrates for suitability. The following backing surfaces are suitable: indoor plastered or papered surfaces, coated plaster. Surfaces must be clean, dry, free from dust, degreased and flat; rough down if necessary. If the product is to be applied to particular backing surfaces, please consult our technical department.

INSTALLATION



Prepare panels, lightly sand edges if necessary with sandpaper grit 150 or finer (breaks).

Wipe edges and panel surface with a damp sponge and dry.

The finish coating can in most cases be applied to the panels before assembly.

Water-based emulsion paints, acrylic or PU-based emulsion paints and alkyd resin paints are suitable. It is always recommended to perform a test coat.



Measure out the wall and establish the position of the individual panels using the spirit level.

Tip:

We recommend beginning the installation in the middle of the wall, so that the panels can later be trimmed to size in the wall and ceiling connection area in order to even out areas where the course of the wall or ceiling is not straight.



Mark the bottom and lateral positioning.



Align and mark the lower laying line with the spirit level.



On the lower laying line, use nails and wooden battens if necessary or nail clamps.



Clamp the adhesive cartridge, cut cartridge nozzle (diameter 5-8 mm).



Apply a continuous line (bead) of ADEFIX® PLUS mounting adhesive to the rear mounting surfaces.



Position the panels and embed them with a sliding movement in the adhesive bed.



With the LIQUID and WAVE models, the use of spacers recommended to keep the distance between the panels uniform. For the other models, spacers can be dispensed with.



Butt joint areas must be not glued or grouted. It should be noted that the connection point remains slightly visible after completion. This is not a reason for complaint.



Measure the size of the panels to be trimmed in the wall and ceiling connection area and transfer to the back of the panels.



Cut the panels to fit (Hand saw with set beam or circular saw with rail).



Further procedure as before.





Professionally grout the ceiling and wall connection area with ADEFIX[®] adhesive filler.



If final painting has not been undertaken before assembly, apply the final coat of paint to the panels after drying (approx. 4 hours).


Water-based emulsion paints, acrylic or PU-based emulsion paints and alkyd resin paints are suitable.

It is always recommended to perform a test coat.

SUPPLEMENTARY INFORMATION

- With the LIQUID and WAVE models, the use of spacers recommended to keep the distance between the panels uniform. For the other models, spacers can be dispensed with.
- Butt joint areas must be not glued or grouted. It should be noted that the connection point remains slightly visible after completion. This is not a reason for complaint.
- With polyurethane materials there may be a slight dimensional change at increased temperature and humidity. A joint up to 2 mm can arise due to these material-specific properties at the panel joint area. This is not a reason for complaint.
- The back of the wall panels is uneven and has cavities. If a panel is mounted such that a cut-side remains visible, it can be smoothly filled with ADEFIX[®] PLUS and ADEFIX[®]. In this case, make sure that the upper surface levelling coat is made only with ADEFIX[®].
- A mitre cut is not recommended.
- Holes and cut outs can be made with standard hole saws, angular cut outs with a jig saw.

For more questions or to order contact:
WallSet Ltd Tel: 0208 610 9988 sales@wallset.co.uk



INSTALLATION VIDEO