

Donner



Owner's Manual

Introduction

The Dynamic Wah is a 100% analog envelope filter for guitar and bass. Four knobs onboard gives you fully access to filter tone characters.

Precautions

READ CAREFULLY BEFORE PROCEEDING

Please keep this manual in a convenient place for future reference.

Power Supply

Always use a DC 9V center negative AC adapter. Use of an adapter other than that specified could damage the unit or cause malfunction and pose a safety hazard.

Always connect the AC adapter to an AC outlet that supplies the rated voltage required by the adapter.

Disconnect the AC adapter from the AC outlet when during lightning storms or not using the unit for an extended period.

Connections

Always turn off the power before connecting or disconnecting. Make sure to disconnect all cables and AC adapter before moving the unit. This will help prevent malfunction and damages.

Environment Considerations

Avoid using the unit in any of the following conditions that could cause malfunction:

- Extremely hot or cold places
- Under direct sunlight
- Magnetic fields
- Near heaters and other heat sources
- Sandy or dusty places
- Places that are extremely humid or exposed to splashing water

- Places with lots of vibrations

Electrical Interference

Devices that are very susceptible to interference or that emits powerful electromagnetic waves (e.g. radios and TVs) should not be placed near this unit, as interference could occur.

Electromagnetic interference could cause malfunction and could corrupt or destroy data.

Always operate this unit at a suitable distance from these devices.

Handling

Do not apply excessive force to the switches and other controls, exposing the unit to strong impacts, which could cause it to break.

Do not put foreign objects or liquids into the unit.

Never open the case or attempt to modify the product in any way since this can result in damage to the unit.

Clean only with a soft, dry cloth.

Overview

● Fully Controllable Envelope Filter

The Dynamic Wah is an envelope filter (or autowah/touch wah) pedal with detailed effect character control. With the four knobs onboard you can easily create the wah sound of your own: you can make some wah sound like you're playing with wah-wah pedals, or go deeper to create something unique and inspiring.

● Easy Controls, Wide Flexibilities

The Dynamic Wah features an easy-to-use four-knob tone control: SENS (filter intensity), RES (filter sharpness), DECAY (filter frequency resting time) and RANGE (filter frequency range) for using in different scenarios or with different instruments. Each knob gives you a wide control range.

● Carefully Selected Components

The Dynamic Wah is designed and built with carefully selected components to ensure best sound quality and road performance. The solid Aluminum-alloy chassis ensures touring reliability, and True Bypass design gives you a transparent tone.


Features

- Compact envelope filter pedal with fast tracking and high accuracy
- 100% analog circuit
- Wide range tone controls for creating your own wah sound
- True bypass provides transparent tone
- LED indicator shows the working state
- Enduring, light-weighted Aluminum-alloy chassis

Specifications

Power Requirement: 9V DC center negative
Current Consumption: 10mA
Dimensions: 42x93.5x52mm
Weight: 230g

Connections & Controls



- A DC 9V Jack:**
For power supply, use a 9-volt DC regulated by AC adapter, 500mA (plug polarity is positive on the barrel and negative in the center).
- B SENS Knob:**
Controls the sensitivity.
- C RES Knob:**
Controls the filter sharpness.
- D DECAY Knob:**
Controls how fast the filter frequency falls back to the resting point.
- E RANGE Knob:**
Controls the filter frequency range.
- F Input Jack:**
1/4" mono audio jack, for connecting guitar.
- G Output Jack:**
1/4" mono audio jack, for connecting to an amplifier.
- H Footswitch and LED:**
Tap to switch the unit on/off. The LED will lit up when the effect is on.



www.donnerdeal.com