

WIRELESS KEYBOARD AND MOUSE SET



QUICKSTART GUIDE

FUNCTIONS AND SPECIFICATIONS



PRODUCT DIAGRAM

1. Battery compartment cover
2. USB receiver
3. Battery compartment
4. USB receiver compartment

SPECIFICATIONS

- 1200 DPI Resolution
- 3 Buttons
- 1 Scroll Wheel
- Auto Sleep Function
- 33ft Working Distance
- 11 x 6 x 3.3cm Dimensions
- 55g Weight
- 1 AA Battery Power Input (Included)



PRODUCT DIAGRAM

1. Battery compartment cover
2. Battery compartment
3. LED Indicator

SPECIFICATIONS

- 78 Keys
- Scissor-Switch Keys
- 2.4GHz Frequency
- 33ft Working Distance
- 28.5 x 12 x 2cm Dimensions
- 294g Weight
- 2 AAA Battery Power Input (Included)

Troubleshooting:

Below are some basic trouble shooting scenarios for the Mouse and Keyboard

Problem	Possible Reason	Solution
Keyboard and mouse are not responsive	<ol style="list-style-type: none"> 1. Batteries are low 2. Batteries have been installed incorrectly 3. Pairing has failed 4. USB Receiver not installed correctly 	<ol style="list-style-type: none"> 1. Replace batteries 2. Ensure batteries are installed correctly 3. Bring Mouse in range of USB Receiver 4. Check to see if USB Receiver is seated correctly

MOUSE CONFIGURATION

1 This mouse is battery-operated and uses one AA battery. To install the supplied battery, remove the battery compartment cover.



2 Once the cover is removed, place the battery in the empty compartment. Install the battery in the correct polarity to work. The mouse's sensor light will flash red once, indicating the battery has been installed correctly.



3 Remove the USB receiver from its compartment.



4 Reinstall the battery compartment cover.



KEYBOARD CONFIGURATION

5 This keyboard is battery-operated and uses two AAA battery. To install the supplied battery, remove the battery compartment cover.



6 Once the cover is removed place the batteries in the empty compartment. Note, the batteries must be placed in the correct polarity to work. The keyboard's red LED light will turn on for 5 seconds then turn off, indicating the battery has been installed correctly.



7 Once the batteries are in place, reinstall compartment cover.



8 Insert USB Receiver in your device or computer's USB port. Once inserted, the mouse and keyboard are ready to use.

