



1500664
User's Guide

RadioShack.



HDMI™ to RF Converter

We hope you enjoy your HDMI to RF Converter from RadioShack. This converter allows you to watch videos and play games on channels 3/4 on non-HDMI devices by converting digital signals to analog. Please read this user's guide before using your converter.


Package Contents

- HDMI to RF Converter
- AC Adapter
- User's Guide

Specifications

Power Supply.....	5V DC
HDMI Connector.....	19-pin Type A Female
HDMI Input Video Signal.....	0.5 - 1.0 V p-p
Support Resolution.....	480i/480p
RF Output Level.....	68± 5dBuV @ 75 Ohms loaded
Impedance.....	75 Ohms


Specifications are subject to change and improvement without notice. Actual product may vary from the images found in this document.



Connect the Converter

Note: Before connecting the converter to your devices, make sure all devices are turned off.

1. Set the output resolution of your device to 480i/480p.
2. Plug the AC adapter cable into the converter's power port and the adapter into a standard wall outlet. The LED indicator turns red.
3. Connect the RF output jack **TO TV** of the converter to your TV or other non-HDMI devices with a coaxial cable (not included).
4. Connect the HDMI cable (not included) to the HDMI port of the HDMI device, and the other end of the cable to the **HDMI IN** port on the converter.
5. Set **CHANNEL** to channel 3 or 4, then select the same channel on your TV.
6. Turn on the HDMI device, and the LED indicator turns green.



FCC Information

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

If you cannot eliminate the interference, the FCC requires that you stop using your equipment. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.



Product	HDMI to RF Converter
Model	1500664
Responsible Party	General Wireless Operations Inc. dba RadioShack 300 RadioShack Circle, Fort Worth, TX 76102
Phone	817-415-3200

Limited Warranty

Go to www.radioshack.com/help for details.
RadioShack Customer Relations
300 RadioShack Circle, Fort Worth, TX 76102

HDMI, the HDMI logo and High-Definition Multimedia Interface are trademarks or registered trademarks of HDMI Licensing LLC.

RoHS Complies with the European Union's "Restriction of Hazardous Substances Directive," which protects the environment by restricting specific hazardous materials and products.



© 2016 General Wireless Operations Inc.
All rights reserved. RadioShack is a registered trademark used by General Wireless Operations Inc. dba RadioShack.
radioshack.com

10A16
1500664
Printed
in China