

STEP 1

IDENTIFY IMPORTANT FEATURES
OF EACH SADDLE



SADDLES ARE MARKED LEFT & RIGHT (SPECIFIC)
FOUR MAGNETS WILL HELP ALIGN & SECURE THE
SADDLE INTO THE CORRECT POSITION

STEP 2

INSERT SADDLE EDGE (SIDE ONE)
INTO HIDDEN CHANNEL



GUIDE THE MAGNET ON EDGE OF THE SADDLE
SECURELY INTO THE HIDDEN CHANNEL
YOU WILL FEEL THE MAGNETS ATTRACT

STEP 3

SLIDE SADDLE TOWARD HEEL



ONCE THE SADDLE IS SECURE IN THE HIDDEN CHANNEL,
SLIDE THE SADDLE "BACK" TOWARDS THE HEEL

STEP 4

ALIGN TOP MAGNET (SIDE ONE)



SECURE THE TOP EDGE OF THE SADDLE WITH THE
CORRESPONDING HIDDEN MAGNET LOCATED IN THE
SHOE, NEAR THE COLLAR

STEP 5

ALIGN TOP MAGNET (SIDE TWO)



REPEAT STEP 4 ON THE OPPOSITE SIDE OF THE SHOE

STEP 6

INSERT SADDLE EDGE (SIDE TWO)
& SLIDE BACK TOWARDS HEEL



REPEAT STEPS 2 & 3 ON THE OPPOSITE
SIDE OF THE SHOE

STEP 7

TIGHTEN LACES AND SECURE
FRONT/ TOP OF SADDLE



AFTER LACES HAVE BEEN TIGHTENED, PUSH DOWN ON
THE FRONT/ TOP OF THE SADDLE TO SECURE IT IN PLACE

STEP 8

SADDLE REMOVAL



PINCH SADDLE AT REAR EDGE
OFF AND AWAY FROM THE SHOE