






	<h3>Step Plate</h3>	<p style="text-align: center;">STEP PLATE OUTSIDE</p> 	
<p>Tools Needed:</p> <p>7/16" Drill Bit Power Drill 7/16" Wrench</p>	<p>Make one mark 1" (25 mm) up from the center of bottom edge of the bottom section and another mark 2-3/16" (56 mm) up from the first mark.</p> <p>Drill a 7/16" (11 mm) hole through the section at each mark and insert the outside step plate.</p> <p>Loosely fasten step plate slide to base with (1) 1/4" - 20 x 5/8" carriage bolt and nut.</p> <p>Align inside step plate holes and fasten from inside using the #8 screws provided. Install one #8 x 3/4" screw in the bottom step plate hole. The screw in the top hole varies with door models.</p> <p>Use the screw size shown below for your model door.</p> <p>a) #8 x 3/4" screw for Model 9100 b) #8 x 1" screw Model 9400/9600</p> <p>Tighten 1/4" - 20 carriage bolt and nut.</p>	<p style="text-align: center;">STEP PLATE BASE</p>  <p>1/4" - 20 X 5/8" CARRIAGE BOLT</p> <p>STEP PLATE SLIDE</p> <p>HEX NUT</p>	<p style="text-align: center;">STEP PLATE INSIDE</p>  <p>ASSEMBLED STEP PLATE</p> <p>(2) #8 SCREWS</p>

	<h3>Pull Rope</h3>	<p style="text-align: center;">NO. 6 SCEW EYE</p>  <p>PULL ROPE</p>	
<p>Tools Needed:</p> <p>Power Drill 1/8" Drill Bit</p>	<p>⚠ WARNING</p> <p>DO NOT INSTALL PULL ROPES ON DOORS WITH ELECTRIC OPERATORS. CHILDREN MAY BECOME ENTANGLED IN THE ROPE CAUSING SEVERE OR FATAL INJURY.</p> <p>Measure and mark the jamb approximately 48" to 50" (1220 to 1270 mm) from floor on the right or left side of jamb. Drill 1/8" pilot hole for No. 6 screw eye. Tie the pull rope to the No. 6 screw eye and to the bottom bracket as shown.</p>	<p style="text-align: center;">NO. 6 SCEW EYE</p>  <p>PULL ROPE</p>	<p style="text-align: center;">BOTTOM BRACKET</p>  <p>PULL ROPE</p>