

KLEVA RANGE
SMARTWATCH



User Manual

Please Read this User Guide carefully before use & keep it handy for future reference.

8. Sports Mode

- Heart rate is measured at the start and every 5 minutes during workouts.
- You can pause/resume workouts and control music during activity.
- After finishing, a summary appears (not saved locally if activity is under 5 minutes).

9. Health Monitoring

Measure heart rate, blood pressure, blood oxygen (SpO2), and ECG directly from the watch.
Wait a few seconds for results to appear. (Requires a watch with a heart rate sensor.)

10. Notifications

When connected to the app, you can receive message alerts. Only the most recent message is displayed on the watch.

11. Calling Features

- Dial Pad: Make calls directly from the dial screen (requires active Bluetooth audio).
- Phonebook: Sync contacts from the app; tap a name to call.
- SOS: Assign emergency contacts in the app. The first contact is default.
- If Bluetooth audio is connected, the call will start automatically.
- If disconnected, a prompt will appear.

SAFETY WARNINGS

To ensure your smartwatch performs well and lasts longer, please follow these guidelines:

Important General Use:

- Do not wear the smartwatch while bathing, swimming, or in the shower unless explicitly rated as waterproof.
- Avoid exposure to high humidity, extreme temperatures, or direct sunlight for extended periods.
- Keep the device away from fire, heaters, and high-pressure environments.
- Do not disassemble or modify the watch or charger.

a. Charging Safety :

- Use only the original magnetic charging cable supplied with your smartwatch.
- Do not charge near water or in damp environments.
- Disconnect the charger immediately if you notice overheating, a burning smell, or unusual noise.
- Avoid charging the watch for more than 2-3 hours continuously.
- Ensure both charging pins are clean and dry before connecting.

b. Battery Care :

- Charge the battery at least once every 1-2 weeks, even if the device is unused, to maintain battery health.
- Avoid fully depleting the battery regularly.
- Do not leave the device connected to the charger overnight.
- Store the watch in a cool, dry place when not in use for long periods.

SAFETY WARNINGS

c. Cleaning & Maintenance :

- Gently wipe the watch and wristband with a soft, lint-free cloth.
- Avoid using alcohol, solvents, or abrasive cleaners.
- Clean the sensor area regularly to ensure accurate heart rate and SpO2 readings.
- If the band becomes wet with sweat, dry it thoroughly before wearing again.

d. Health & Comfort :

- Wear the smartwatch loosely enough to allow skin to breathe.
- Remove the watch periodically to let your skin rest.
- If skin irritation or redness occurs, stop wearing it and consult a physician if needed.

e. Data & Connectivity :

- Keep the smartwatch connected to the app for accurate data synchronization.
- Reboot the smartwatch or phone if Bluetooth connection becomes unstable.
- Always back up important fitness or health data in the app.

f. Storage :

- Store in a clean, dry place when not in use.
- Keep out of reach of children and pets.
- Avoid leaving the smartwatch inside a car or near windows under direct sunlight.

1. Adjusting Your Wristband

Insert the wristband into the watch face and adjust it to fit your wrist using the adjustment holes. Fasten the buckle securely. Ensure that the sensor on the back of the watch rests snugly against your skin and does not move during use.

2. Charging Your Smart Watch

Before first use, charge your smartwatch fully. If the device cannot power on due to low battery, connect it to the magnetic charging cable and plug the other end into a power source.

3. Installing the App

Scan the QR code provided to download and install the FitPro app, or search for "FitPro" in the App Store (iOS) or Google Play Store (Android). You can also use the same QR code to bind your smartwatch directly.



4. Connecting Your Device

- Turn on Bluetooth on your smartphone.
- Open the FitPro app and connect to the device listed as "KLEVA Smart Watch."
- Once paired, the time and other settings will automatically sync.

To remove the smartwatch:

Go to the FitPro app settings -> tap "Remove Device" -> confirm -> disconnect Bluetooth.

The app will remember your smartwatch's Bluetooth address and automatically reconnect when opened or running in the background.

To ensure full functionality, grant the app all required permissions, including notifications and background activity.

5. Basic Watch Operations

Knob Functions:

- Short press: Activate screen.
- Rotate: Switch between watch faces or menu items.
- Long press: Power On/Off, Reset, or activate SOS.
- Use to zoom in/out in the honeycomb-style menu.

Gestures:

- Swipe down: Information page.
- Swipe up: Control menu.

6. Control Center Features

- Bluetooth Calls:
- If no audio connection occurs within 5 minutes of startup, the feature will automatically turn off.
- If disconnected for more than 1 minute, the audio Bluetooth will automatically disable until reconnected.

- Dial Style: Rotate the knob to switch between dial themes.

- Music Control: Play, pause, skip to next/previous song.

- Flashlight: Tap the flashlight icon for a white screen; swipe to exit.

- Do Not Disturb: Toggle to mute notifications.

- Airplane Mode: Disable Bluetooth and wireless connections.

7. Health Tracking Rings

- Steps (Outer Ring): Counts daily steps, resets at midnight. Set your step goal in the app.

- Exercise (Middle Ring): Tracks total exercise duration per day, resets at midnight.

- Stand (Inner Ring): Records standing sessions (20+ consecutive steps per hour).

Progress can be viewed as a ring chart on your watch or in the FitPro app.

19. Other Applications

Built-in apps include Facebook, WhatsApp, Twitter, Calculator, and Calendar.

20. Settings

- About: Device information.

- Voice Assistant: Tap screen to activate; press knob to exit.

- Language: Change system language.

- Date & Time: Adjust manually if needed.

- Backlight Duration: Choose how long the screen stays on.

- Auto Return: Set time before the screen returns to the home dial.

- Bed Lamp Mode: Keeps charging screen on; press knob to turn off.

21. App Functions

- Profile Setup: Enter gender, age, height, weight, and daily step goals.

- Notifications: Enable app notifications (grant all system permissions).

- Alarms: Set up to 8 alarms, which sync with the smartwatch and work offline.

- Find Device: Tap "Find" in the app to locate your watch.

- Dial Customization: Select and sync different watch faces.

- Sedentary Reminder: Get alerts if you've been sitting too long.

- Device Reset / Remove: Clear data and disconnect the device.

22. Specifications

Battery	3.7V 200mAh
Input	5V / 1A
Operating Temp	10°C to 50°C
G-Sensor	Supported
Vibration Moter	Supported
System Compatibility	iOS 9.0+ / Android 5.0+
Bluetooth Name	KLEVA Smart Watch
App Name	FitPro
Model Number	KSMAR-WTCH

KLEVA RANGE

W. www.klevarange.com.au
P. 02 9387 4100
E. support@klevarange.com.au
A. Suite 301 / 209 Oxford St
Bondi Junction NSW 2022 Australia