



Tough Leads

Tough leads for tough applications

10mA RCD Conversion Kit Instructions

Fitting Instructions

Step 1 - Remove the cable from the current plug RCD:

- Unscrew the cover.
- Remove the cord grip.
- Unscrew the terminals.
- Remove the wires.

Step 2 - Fit the new inline RCD:

- Unscrew the RCD cover which is at the opposite end to the plug.
- Remove the cord grip.
- Ensure all 3 terminals are loosened.
- Push the cable into the RCD gland. A small amount of lubricant may be necessary.
- Insert the brown wire into the terminal marked 'L'.
- Insert the blue wire into the terminal marked 'N'.
- Insert the green/yellow wire into the terminal marked 'E'.
- Ensure all terminals are tight - loose connections can lead to over heating.
- Push the cable flex into the RCD, so that 3-4mm is showing past the position of the cord grip.
- Screw down the cord grip. Tug the cable to ensure that it is tightly held in place.
- Ensure that the wires are lying in a position where they will not be trapped or damaged by the cover.
- Place the cover onto the RCD and screw down.

Operating Instructions

- Plug in the 13A plug to a suitable 13A socket.
- Press the 'RESET' button.
- The RCD will latch on, and remain so until the power supply to the RCD is turned off.
- Press the 'TEST' button regularly to check for correct operation. After 'TEST', press the 'RESET' button.

Specification

Voltage	230v
Current	13A
Trip current	10mA
Waterproof rating	IP66 (protected against powerful water jets from any angle).