


# BOOGIE BOUNCE OWNER'S MANUAL

## Contents

1. Safety Instructions
2. Care and maintenance instructions
3. Assembly Instructions
4. Disassembly Instructions
5. Warranty



Note: SkyBound is the only authorized dealer to supply, promote, and sell of Boogie Bounce Elite Trampoline in North America.

[www.SkyBoundUSA.com](http://www.SkyBoundUSA.com)  
[www.TrampolinePartsCenter.com](http://www.TrampolinePartsCenter.com)

## A PERSONAL MESSAGE FROM TEAM SKYBOUND

When I shop, I am not just buying a product or service. I purchase why that brand focuses on what they do, what their corporate philosophy is, the quality of their products, and whether or not my personal core values align with that brand's vision. When I don't feel great about a company's brand, products, or how I'm being treated as a customer, then I know they are not delivering on what matters most: exceeding the customer expectation by delivering happiness with their products, quality, and service.

This primary focus is what drives our culture at Team Skybound. For supporting our vision, we would like to personally thank you for trusting us to deliver happiness to you and your family!

Team SkyBound

*"Nurturing the inner-child in all of us by uniting communities worldwide and promoting an active lifestyle."*

For customer service, please contact:

888-891-4689

Monday through Friday

8:00 am to 5:00 pm PST

or visit [www.SkyBoundUSA.com](http://www.SkyBoundUSA.com)

or [www.TrampolinePartsCenter.com](http://www.TrampolinePartsCenter.com)



[help@skyboundusa.com](mailto:help@skyboundusa.com)

# Safety Instructions

1. **Important** - Equipment unsuitable for children under 6 years and children over 6 years must be supervised at all times.
2. **Important** - Children under 14 years must use equipment with safety cover fitted. Please see assembly instructions.
3. Familiarize yourself with the Boogie Bounce Elite owner's manual.
4. Watch all safety and instructional introductory videos on the Boogie Bounce App.
5. The trampoline shall be assembled by an adult in accordance with the assembly instructions and thereafter checked before the first use.
6. This equipment is to be used only in conjunction with the Boogie Bounce fitness programme.
7. Only for domestic use.
8. For indoor use only.
9. Misuse of this equipment can cause serious injury and or death.
10. Place the trampoline on a flat and level surface.
11. Do not use mat while wet.
12. Ensure that each Boogie Bounce trampoline and T Bar handle is inspected in accordance with the care and maintenance section of this manual.
13. Ensure that the floor area around the trampolines is free from any trip hazards.
14. Empty pockets and hands before jumping.
15. Do not eat while jumping.
16. Always step on and off the trampoline with great care and if necessary, use the T Bar handle as a balance aid.
17. Do not, at any time subject the T Bar handle to your full body weight. The T Bar Handle is only there as an aid to balance.
18. Do not jump on or off the trampoline as this may cause injury to you or those around you.
19. Overhead clearance is extremely important. Make sure that there is adequate headroom to avoid any possibility of the individual that is bouncing coming into contact with any surface or protrusion from above including ceilings, light fittings, fans, sprinkler systems, support beams or any other high level object.

20. This equipment is to be used only in conjunction with the Boogie Bounce Home Programme App or DVD. Stay within your own abilities. Do not attempt to carry out any moves that you are not confident with. Push down into the mat and keep the bounce low and in beat to the music. Only attempt some of the more dynamic manoeuvres when you are confident to do so.
21. Only execute moves on the trampoline as demonstrated on the Boogie Bounce Home Programme App.
22. Stay within the yellow outer rim of the trampoline mat. This is 25.4in in diameter.
23. If you feel faint or dizzy immediately stop bouncing and carefully step off the trampoline using the T Bar handle as a balance aid.
24. Always bounce within the centre of the mat. Do not extend out beyond the edge of the mat.
25. The Boogie Bounce trampoline is designed for use by only 1 person at a time. Collision Hazard.
26. No Somersaults.
27. Do not exit by a jump.
28. Make sure that you have an adequate supply of drinking water.
29. The weight limit of the trampoline is 280 lbs.
30. Maintain adequate space around the trampoline to ensure that there is no danger of coming into contact with another object or person.
31. Do not use while wearing shoes.
32. It is advised to wear non-slip socks. Bare feet or ordinary socks are not safe due to lack of grip.
33. Always store the Boogie Bounce equipment in a dry storage facility. Do not allow the equipment to get wet.


## Care and Maintenance Instructions

1. Inspect the Boogie Bounce trampoline and T Bar handle before every use of the equipment.
2. Check that all 6 legs and the base section are correctly fitted on the trampoline with rubber feet on each of the legs.
3. Ensure that all legs are inserted correctly and securely as shown in the assembly instructions.
4. Check that the locking pin holding the T Bar to the handle base is fully located and locked in position.
5. Ensure that the two locking pins that fit into the hinge sections on the main trampoline frame are locked in position before stepping onto the trampoline.
6. Check the trampoline mat and replace if there are any tears or rips to the material.
7. Check the trampoline mat and replace if the stitching shows any sign of fraying or damage.
8. Check the trampoline mat for sag and replace if necessary.
9. Check that there are no broken or damaged bungees or bungee clips around the mat perimeter. Replace as necessary.
10. Check the T Bar handle vertical pole has not been bent or distorted.
11. Check for any sharp protrusions that may cause injury.
12. Do not use anti-bacterial sprays or wipes to clean the trampoline mats. It will rot the stitching causing failure of the mat around the securing loops that attach to the frame. Use only plain soapy water to wash the trampoline mat or 'Clean Freek' products, which are not damaging to the mat and can be found on the Boogie Bounce website.
13. The total weight of The Boogie Bounce Elite Trampoline and Handle is 20 lbs.

## Assembly Instructions


### STEP 1

Remove all components from the Boogie Bounce Elite carry case.




### STEP 2

Stand trampoline on its edge and slot legs on. Locate legs into secured position.




### STEP 3

Once legs are in position this is what you should see.



### STEP 4


Insert final leg and handle tube section and ensure it is securely in place as shown.



# Assembly Instructions


## STEP 5

Allow to rest half-way open and insert handle.



## STEP 6

Insert pin to secure handle in place and securely fasten safety clamp.




## STEP 7




**IMPORTANT STEPS. FAILURE TO FOLLOW INSTRUCTIONS MAY RESULT IN INJURY.** Fully unfold trampoline. Stand on edge of frame and use handle to push down. Before removing foot from frame, insert pin to secure in position. **DO NOT REMOVE FOOT FROM FRAME UNTIL FIRST PIN IS INSERTED.**

# Assembly Instructions






# Assembly Instructions



## STEP 8

Insert the pin on the other side.



# Assembly Instructions




**Important** - Safety cover must be fitted before equipment is used by anyone under 14 years. Equipment must not be used by anyone under 6 years.


**Step 1:** Remove handle pole and fit safety cover around the edge of the trampoline frame. Line up the hole in the safety cover with the handle pole tube.

**Step 2:** Fit safety cover over the handle pole tube and ensure the it is fitted correctly all the way around the frame.

**Step 3:** Use the ties to fix the safety cover to the trampoline frame. Then insert handle pole back into tube.



# Disassembly Instructions



**IMPORTANT  
DISASSEMBLY  
INSTRUCTIONS  
READ BEFORE USE  
FAILURE TO DO SO MAY  
RESULT IN INJURY**

# Disassembly Instructions


## Disassembly Instructions



**IMPORTANT STEPS TO FOLD TRAMPOLINE.  
FAILURE TO FOLLOW INSTRUCTIONS MAY  
RESULT IN INJURY.**

- a) REMOVE ONE PIN FROM TRAMPOLINE HINGE.
- b) KEEP ONE FOOT ON BACK EDGE OF TRAMPOLINE FRAME AND HOLD HANDLE WITH ONE HAND WHILE REMOVING SECOND PIN FROM HINGE WITH OTHER HAND. DO NOT REMOVE SECOND PIN WITHOUT FOOT AND HAND BEING IN PLACE AS EXPLAINED.
- c) NEXT, GENTLY PULL HANDLE TOWARDS YOUR BODY. DO NOT REMOVE FOOT FROM FRAME OR REMOVE HAND FROM HANDLE UNTIL THE TRAMPOLINE IS FOLDED.
- d) SEE IMAGES ON NEXT PAGE.

# Disassembly Instructions



# Warranty

## Boogie Bounce Trampoline/Stability Handle Warranty

Boogie Bounce Xtreme Ltd warrants its trampoline/stability handle equipment to be free from defects in design, material and workmanship under normal use and service conditions. The various component parts of the trampoline and T Bar stability handle are warranted against defects as follows:

### Trampoline.

A. Steel frame. Twelve (12) months; B. Sewing on stitched jumping mat. Twelve (12) months; C. Clips and bungees. Twelve (12) months.

### Stability Handle.

A. All Steel sections and welds. Twelve (12) months. B. Locking pins. Twelve (12) months. Note: Foam grips are not included in the warranty.

This warranty only applies if the equipment has been used, maintained, and stored in accordance with the user instructions and owner's manual supplied with this equipment.

All warranty coverage extends only to the original purchaser and begins from the date of purchase. Boogie Bounce's obligation under this warranty is limited to replacing or repairing the equipment, or refunding the price paid, at Boogie Bounce's option.

If you want to make a warranty claim or contact customer services, please go to <https://www.skyboundusa.com/pages/warranty-form>.