



USER MANUAL

ASSEMBLY, INSTALLATION, CARE,
MAINTENANCE AND USER INSTRUCTIONS

www.SkyBoundUSA.com

WARNING

- Prior to assembling or using the trampoline, you must thoroughly read this manual.
- Keep this manual for future reference.
- This product is intended for domestic family use only.
- Adult supervision is required at all times.
- This trampoline is not intended for use by more than one person at any time.
- This product is recommended for use by children 6 years of age or older.
- Maximum weight of the user not to exceed 175 lbs (79.4 kgs).

A PERSONAL MESSAGE FROM OUR CEO

When I shop, I am not just buying a product or service. I purchase why that brand focuses on what they do, what their corporate philosophy is, the quality of their products, and whether or not my personal core values align with that brand's vision. When I don't feel great about a company's brand, products, or how I'm being treated as a customer, then I know they are not delivering on what matters most: exceeding the customer expectation by delivering happiness with their products, quality, and service.

This primary focus is what drives our culture at Team SkyBound. For supporting our vision, we would like to personally thank you for trusting us to deliver happiness to you and your family!

-Kiki (CEO) & Team SkyBound

"Nurturing the inner-child in all of us by uniting communities worldwide and promoting an active lifestyle."

For customer service, please contact:
888-891-4689
Monday through Friday
8:00 am to 5:00 pm PST
or visit www.SkyBoundUSA.com



help@skyboundusa.com

IMPORTANT INFORMATION

Trampolines are a healthy, fun form of exercise when used properly. Most injuries are caused due to improper use, not because of their construction.

Read the following instructions and warnings to ensure the trampoline is safe to use and lasts as long as possible, follow all assembly and maintenance instructions at all times.

WARNING - GENERAL

Prior to using the trampoline, you must read all the instructions contained in this manual. All information, including the warnings instructions for care, maintenance, and use of the trampoline are intended to promote safe, enjoyable use of the trampoline.

- Overhead clearance is essential. A minimum of 24 feet of overhead clearance from ground level is required.
- Provide clearance for wires, tree limbs, and other possible hazards.
- Lateral clearance is essential. Place the trampoline away from walls, fences, structures, and other play areas. Maintain a clear space on all sides of the trampoline.
- Place the trampoline on a stable level surface before use.
- The area under the trampoline surface should be free and clear of any objects or obstructions.
- Use the trampoline in a well-lit area. Artificial illumination may be required for indoor or shady areas.
- Secure the trampoline against unauthorized and unsupervised use.
- Remove any obstructions from beneath the trampoline.
- The owner and supervisors of the trampoline are responsible for all users to be aware of the practices specified in the use instructions.
- This product is not intended for use by children under 6 years of age. Restrict usage to one person at any time. Maximum weight limit is 175 Lbs (79.4 kgs).
- Prior to each use, inspect the trampoline for any worn, defective, misadjusted or missing parts. Ensure the frame padding is correctly and securely positioned.

WARNING - USAGE

- DO NOT attempt or allow somersaults. Landing on the head or neck can cause serious injury, paralysis, or death, even when landing on the middle of the bed.
- Do not allow more than one person on the trampoline. Use by more than one person at the same time can result in serious injury.
- Use trampoline only with mature, knowledgeable supervision at all times.
- Inspect the trampoline before each use. Make sure the frame padding is correctly and securely positioned. Replace any worn, defective, or missing parts.
- Climb on and off the trampoline. It is a dangerous practice to jump from the trampoline to the floor or ground when dismounting, or to jump onto the trampoline when mounting. Do not use the trampoline as a springboard to other objects.
- Stop bounce by flexing knees as feet come in contact with the trampoline bed. Learn this skill before attempting others.
- Learn fundamental bounces and body positions thoroughly before trying more advanced skills. A variety of trampoline activities can be carried out by performing the base fundamentals in various series and combinations, performing one fundamental after another, with or without feet bounces between them.
- Avoid bouncing too high. Stay low until bounce control and repeated landing in the center of the trampoline can be accomplished. Control is more important than height.
- While keeping the head erect, focus eyes on the trampoline toward the perimeter. This will help control bounce.
- Avoid bouncing when tired. Keep turns short.
- Properly secure the trampoline when not in use. Protect it against unauthorized use.
- Keep objects away that could interfere with the performer. Maintain a clear area around the trampoline.

WARNING - USAGE

- For additional information concerning trampoline equipment, contact SkyBound (www.SkyBoundUSA.com); help@skyboundusa.com
- For information concerning skill training, contact a certified trampoline instructor.
- Bounce only when the surface of the bed is dry. Wind or air movement should be calm to gentle. The trampoline must not be used in gusty or severe winds.
- Read all instructions before using the trampoline. Warning and instructions for the care, maintenance, and use of this trampoline are included to promote safe, enjoyable use of the equipment.
- Remove any sharp or loose objects from pockets or on your body prior to use, including such as glasses, watches, jewelry, chains, ornaments, clasps and other sharp objects.
- Ensure the trampoline and surrounding areas are properly illuminated.
- Do not put any objects on, under or around the trampoline.
- Shoes should not be worn while jumping on the trampoline. Jumpers should be barefoot, or wearing socks or gymnastics shoes.
- Serious injury can occur from misuse or abuse of the trampoline. Bounce in the center of the bed.

CARE, MAINTENANCE AND USE INSTRUCTIONS MUST BE READ CAREFULLY PRIOR TO USING THE TRAMPOLINE!

This Trampoline is constructed of high quality materials and craftsmanship. For years of exercise, fun and enjoyment and to reduce the risk of injury to the user, follow all required care and maintenance instructions closely listed below:

- Only one jumper should use the trampoline at any time.
- Do not allow pets on the trampoline in order to help prevent cuts, scrapes, tears or other types of damage to the mat or pad.
- Inspect the trampoline before each use and replace any worn, defective, or missing parts. Any number of issues can raise the risk of injury.
- The following conditions could represent potential hazards:
 1. Missing, improperly positioned, or insecurely attached frame padding
 2. Punctures, frays, tears, or holes worn in the bed or frame padding
 3. Deterioration in the stitching or fabric of the bed or frame padding
 4. Ruptured springs
 5. A bent or broken frame
 6. A sagging mat
 7. Sharp protrusions on the frame or suspension system

IF ANY OF THE PREVIOUS CONDITIONS ARE FOUND, OR ANY OTHER ISSUES YOU FEEL MAY BE HARMFUL TO THE USER, THE TRAMPOLINE SHOULD BE IMMEDIATELY DISASSEMBLED OR SECURED FROM ANY FUTURE USE UNTIL THE ISSUE(S) HAVE BEEN RESOLVED.

You must check all the parts of the trampoline including the frame, suspension system, mat, pad, and enclosure at regular intervals. If these checks are not carried out, the trampoline could become dangerous.

It is of particular importance that these be followed at the beginning of each season, as well as at regular intervals during the usage season.

- Check all nuts and bolts for tightness and tighten as required.
- Check all coverings for bolts and sharp edges and replace when necessary.
- Check for evidence of wear and tear or deterioration and damage. Replace any parts as needed.

HIGH WIND ADVISORY

Please keep in mind, this trampoline can be blown around by high winds. During times of high winds, the trampoline should be moved indoors to a sheltered location.

U.S. Patent No. D794151

ASSEMBLY PARTS LIST


Please reference the list of parts below for assembly of the trampoline.
Prior to constructing, please make sure all parts listed below are accounted for.



A
8 FT OCTAGON TRAMPOLINE PAD



B
8 FT OCTAGON TRAMPOLINE MAT



C
8 FT OCTAGON TRAMPOLINE NET



D
T-POLE WITH BALL JOINT x8




E
TOP RAIL x8



F
J-POLE WITH FOAM x8



G
CURVED POLE WITH FOAM x8



H
5.5" SPRINGS x48




I
FOOT WITH LOCK x8



J
ROPE x4




K
SMALL BOLT x16




L
FEMALE BOLT x16




M
LONG BOLT x8



N
CAP NUT AND WASHER x8



O
WRENCH x1



P
ALLEN KEY x2



Q
SPRING TOOL x1



R
HOOKED STRAP x8






S
ANCHOR KIT x8





T
PLASTIC GUIDE x1

ASSEMBLY INSTRUCTIONS

STEP 1



STEP 2



***Note:** If you are having issues connecting the last Top Rail, the frame is not properly positioned. To correct this, have one person hold the problem corner in place, while the second person gently pulls on the opposite corner to readjust the frame.



It is highly recommended for two people to assemble the trampoline. This package contains small parts which are a choking hazard and may have sharp edges and points. Keep all parts away from children until fully assembled.

ASSEMBLY INSTRUCTIONS




WARNING

Do not lift or move trampoline during installation! Doing so may warp the frame making the rest of the installation process difficult.

STEP 3



B
8 FT OCTAGON TRAMPOLINE MAT





H
5.5" SPRINGS x48



Q
SPRING TOOL x1

Align the 8ft Octagon Trampoline Mat (B) to the trampoline frame by matching up the corners with each other.

***Note:** Follow the order shown in Figure 1 and Figure 2 respectively in order to ensure even distribution of tension, preventing warping the frame.



connect to frame connect to mat's V-rings







***Note:** The spring hook that is more curved should be connected to the mat's V-rings. The less curved/open hook should then be pulled into the spring holes on the frame using the spring tool (Part Q).



Complete installation of the Trampoline Mat after connecting the 32 springs shown in Figure 1 and 2 by connecting the remaining 16 springs.

ASSEMBLY INSTRUCTIONS



STEP 4

F
J-POLE WITH FOAM x8


M
LONG BOLT x8

N
CAP NUT AND WASHER x8

O
WRENCH x1

P
ALLEN KEY x2

STEP 5



A
8 FT OCTAGON TRAMPOLINE PAD



It is highly recommended for two people to assemble the trampoline. This package contains small parts which are a choking hazard and may have sharp edges and points. Keep all parts away from children until fully assembled.

ASSEMBLY INSTRUCTIONS



WARNING

Do not lift or move trampoline during installation! Doing so may warp the frame making the rest of the installation process difficult.


STEP 6




A
8 FT OCTAGON TRAMPOLINE PAD




R
HOOKED STRAP x8



Tie the hooked strap to the loops on the inner seam of the Trampoline Pad.



The plastic hooks under the pad should be connected to the trampoline's v-rings.



The elastic bands under the pad should be tied to the nearest v-rings.

STEP 7



G
CURVED POLE WITH FOAM x8



Insert Curved Pole(s) with Foam (G) into the J-Pole with Foam (F). Make sure to align push pin with the hole on the J-Pole. Repeat for all 8 poles.



It is highly recommended for two people to assemble the trampoline. This package contains small parts which are a choking hazard and may have sharp edges and points. Keep all parts away from children until fully assembled.

ASSEMBLY INSTRUCTIONS

STEP 8



C
8 FT OCTAGON TRAMPOLINE NET



J
ROPE x4



T
PLASTIC GUIDE x1

To attach the bottom of the Trampoline Net (C) weave the Rope (J) through the net and the mat's v-rings. Use the plastic guide (T) to help guide/pull the rope. Make sure to tie both ends. See Figures 3 - 5 for reference.




FIGURE 3




FIGURE 4




FIGURE 5



It is highly recommended for two people to assemble the trampoline. This package contains small parts which are a choking hazard and may have sharp edges and points. Keep all parts away from children until fully assembled.

ASSEMBLY INSTRUCTIONS



WARNING


Do not lift or move trampoline during installation!
Doing so may warp the frame making the rest of the installation process difficult.

STEP 9

S

ANCHOR KIT

x8



ENJOY YOUR NEW





IMPORTANT WARRANTY INFORMATION



For full warranty information on
your SkyBound product please visit:
<https://www.skyboundusa.com/warranty>



SKYBOUND