



◆ OPENING THE BANGLE ◆

The **clasp** is made of a tiny catch that securely locks the bangle.




Step 1:
Locate the dot near the clasp.


Step 2:

Place your thumb above the side with the dot.

Hold the opposite side with your hand.




Ensure that your index finger is not underneath the side with the dot.




Step 3:

Gently press down (not forward) and push open to release the clasp.



◆ TAKING OFF THE BANGLE ◆


Insert a finger between the Bangle and your wrist, then press with your thumb on the side with the dot.



◆ CHANGING THE SILK ◆


Inserting the Silk:

Put the Silk Slide in place along the grooves of the metal frame.



Removing the Silk:

Lift up the Silk Slide using the metal tab.



◆ PRODUCT CARE ◆

To clean the Silk Slides, handwash with lukewarm or cold water and a gentle detergent. Do not soak.

The Bangle is best cleaned with a soft facial tissue and some rubbing alcohol.

Should any tarnishing occur, gently wipe with a jewellery polishing cloth.