

Pitching your POD



STEP 1 - Grab a beer (optional), unpack and check you've got all your bits! You should have:

- a set of 12 pegs
- a small pole
- a small guy rope
- a POD with sewn in groundsheet



STEP 2 - Lay the POD in the general position that you want it (if you're pitching with a glanopy then remove the A-frame at this stage, making sure that the rest of the glanopy is supported so it doesn't fall over)

Pop the POD eyelet over the top of the A-frame



STEP 3 - Peg out the POD so that it remains symmetrical with the A-frame position and maintains the correct shape.

If using with the glanopy, the pod should go underneath the glanopy, as shown above, so that the glanopy can overlap the gap. It also helps to keep the main glanopy guy rope in place.



STEP 4 - Pop the pole in at the base of the POD as shown above. This gives the tent the correct structure and allows for ventilation.



STEP 5 - TOP HACK: If you want to ensure you close the gap between the glanopy and the POD as much as possible you can clip 22mm plumbers pipe clips over the canvas and A-frame poles, as shown above.



STEP 6 - Admire your handiwork and grab another beer (unless you're still finishing your first, of course).

If it doesn't look like the picture above, go back to step 1. If it still doesn't, stop drinking beer and give us a call...