

EVERLAST CLIMBING INDUSTRIES, INC.

INSTALLATION INSTRUCTIONS: 4' x 4' PANEL



Materials Included:

Panels
Sleeve Anchors

Tools Needed:

Level
Wood Shims
1/2" Hammer Drill Bit

Drill
Socket Wrench
Wood Block


INSTALLATION INSTRUCTIONS:

(Please read all instructions thoroughly before starting to install)


1. Set the first 4'x4' panel on a wood block that is taller than the existing baseboard. Staying above the baseboard allows for future servicing and maintenance of your floor.
2. Place a 4' level on top of the first panel, making sure the edge is clear of debris. Shim the panel so that it is perfectly level. (You can double-check this by using the level to plumb the side of the panel, but the top is a more trustworthy surface.) It is very important that the first panel be exactly level, since it will affect the remainder of the wall.
3. Hold the panel firmly in place and using a 1/2" hammer drill bit, drill through one of the corner mounting holes. The mounting holes are larger, empty holes, without T-nuts.
4. Insert one of the 1/2" sleeve anchors provided, and tighten it down using a socket wrench. Tighten the sleeve anchor until snug - do not overtighten!. If sleeve anchor starts to spin, pull out on the bolt head to "set" the cone in the sleeve.
5. Repeat steps #3 & #4 for the remaining three mounting holes.
6. Place the second 4'x4' panel on top of the first. Make sure this panel is flush with the first panel and does not stick out on either side. Try orientating the panels in different directions so the wall does not appear repetitive.
7. Repeat steps #3-#6 to install the remainder of the panels and complete your climbing wall.




Sleeve
Anchor




Mounting Holes



Step #1



Step #2



Step #3



WARNING

THE PROPER CARE AND ONGOING MAINTENANCE OF YOUR CLIMBING WALL IS ESSENTIAL AND IS YOUR RESPONSIBILITY. PLEASE REFER TO THE SAFETY, CARE AND MAINTENANCE INSTRUCTIONS.