




# VAS SHROUD


FITS STANDARD  
US ARMY MOUNT ARM  
#A3256368

V I S U A L   A U G M E N T A T I O N   S Y S T E M

***Why carry around extra weight when you're not wearing NVGs?***

- ▶ Fits any standard MARSOC / WARCOC 3-hole NVG mount pattern
- ▶ Snag free for HALO, HAHO and static line
- ▶ Weighs only 34 grams
- ▶ Available in the following colors:

 Foliage Green


 Urban Tan

 Black



MADE IN USA

06-05-100 REV. B





## STEP 1: ATTACH SHROUD TO HELMET

Align the VAS Shroud with the existing 3-hole pattern on the front of your helmet. Insert a T-nut through the Shroud's top hole from the front (outside) of the helmet shell and use your fingers to loosely attach a screw from the inside of the helmet shell. Repeat for the remaining 2 holes.

Finish by using a screwdriver to tighten all 3 screws from the inside of the shell, making sure the VAS Shroud is securely fastened to the helmet.


## STEP 2: FOAM BACKER

The optional foam backer is included to stick on the back of the mount arm plate. This backer can reduce wiggle or vibration between the shroud, mount arm, and helmet.



## STEP 3: ATTACH NVG MOUNTING ARM

Insert and anchor the top of the NVG Mounting Arm underneath the top of the bracket as shown. While pressing the arm's release trigger, push down to snap and lock the arm in place.



## STEP 4: PULL TEST

Before attaching any NVG's to the mount, give it a sturdy tug in all directions to ensure it is properly secured.

**VAS SHROUD IS COMPATIBLE WITH ACH, OPS-CORE FAST AND SENTRY HELMETS. CORRESPONDING HARDWARE WILL BE INCLUDED FOR HELMET VERSIONS.**



Ops-Core, Inc.  
12 Channel Street  
Boston, MA 02210

**[www.ops-core.com](http://www.ops-core.com)**