



HOW TO USE - MOUSE PAD:

- 1 Place the mouse pad on a clean, flat surface to either the right or left side of your keyboard. Then place your wrist on the raised ergonomic support at the bottom of the wrist pad.




HOW TO CLEAN:

- 1 Wipe clean with a damp cloth.



HOW TO USE - WRIST SUPPORT:

- 1 Place the wrist support on a clean, flat surface directly underneath a keyboard.
- 2 When typing place both wrists on the wrist support. The wrist of your dominant hand should rest at the narrowest part of the wrist support. There is a small indented groove in the memory foam, indicating the correct spot to rest the wrist of your dominant hand on the wrist support. The wrist support can be rotated 180 degrees.



Do not use soap or any other cleaning agents as it may cause damage to the products.



HAVE AN ISSUE WITH YOUR MOUSE PAD AND WRIST SUPPORT?

Enjoy hassle-free replacements: if your mouse pad and wrist support are defective or damaged, we will ship you a new one ABSOLUTELY FREE.

For fast and knowledgeable service, get in touch with one of our customer service experts right now!


WRITE A MESSAGE
TO SUPPORT



Email: support@upperechelonproducts.com

To check out more of the products we offer visit:

everlastingcomfort.net



Ergonomic Mouse Pad with Wrist Support

USER MANUAL