



SALES

800-365-6060

TECH SUPPORT

833-AIS-TECH

WWW.AISINTERFACE.COM



AUTOMOTIVE INTEGRATION SOLUTIONS

CDJMOD

4.3", 5", AND 8.4"

CHRYSLER, DODGE, JEEP, RAM

REVERSE CAMERA INTERFACE

INSTALLATION MANUAL

www.aisinterface.com

Applications

2013 - 2017	2015 - 2016	2014 - 2017
RAM	Charger/Challenger	Durango/Grand
4.3", 5", 8.4"	5", 8.4"	Cherokee
Screen Size	Screen Size	5", 8.4"
		Screen Size

Parts inside the box**Wiring Diagram and In-**

Step 1) Remove factory radio. Connect male end of the T-Harness provided into the radio. Connect the female end into the car side of the radio harness.

Step 2) Connect the **WHITE** wire to the camera's 12V+ wire,

Step 3) Connect the **BLACK** wire to the camera's ground wire.

Step 4) ONLY for manual activation for Video N Motion, Connect the **GREEN** wire to one side of a 12V switch. (not provided) Connect the other side of the switch to 12V+ source.


Step 5) Connect the camera's RCA to the RCA input.

Step 6) Set DIP switches. (see Setting Dip Switches)

Step 7) With all the DIP switches in the OFF position, plug the 8 pin Molex plug into the module.

Step 8) Start vehicle. Once the radio has fully booted up, put DIP switch #2 into the on position. The radio may or may not reboot. Once the radio has rebooted, turn the vehicle off and with everything closed, lock the car and wait 15 min.

Step 9) After 15 min, unlock the vehicle and test.

Wiring Diagram and Installation**Dip Switch Settings and Programming****DIP Switch**

- 1) If "ON" Activates Video N Motion
- 2) Activates rear camera
- 3) N/A
- 4) N/A
- 5) CAN — Radio Side
- 6) CAN — Car Side

DIP 1	DIP 2	DIP 3	DIP 4	DIP 5	DIP 6
ON	ON	OFF	OFF	OFF	OFF
OFF	ON	OFF	OFF	OFF	OFF