



PARTS LIST

Reference	Qty	Description	Reference	Qty	Description
A	(4)	61-1/4" Tube	1	(2)	10-8 Kee Klamp
B	(10)	61-1/4" Tube with swag	2	(2)	15-8 Kee Klamp
C	(3)	20-1/2" Tube	3	(2)	25-8 Kee Klamp
D	(2)	12" Braces	4	(2)	12-8 Brace Fitting

Qty	Description	Qty	Description
(3)	2" i.d. PVC ground sleeves	(1)	Vinyl Skirt
(1)	Pole Cap	(10)	Release Ty-raps
(1)	Rebound Net	(1)	Webbing Strap
(30)	Bungee Cords	(1)	Set Screw Key
(20)	Adjustable Straps		



1. Sink PVC sleeves to a depth of 2' in concrete that is at least 3' deep; as shown on the illustration. Note that the center pole is set back from the (2) end poles.
2. Assemble bottom bar over the holes as a guide. Lift off, lay down and finish assembly of frame on the ground. Use the set screw key to secure poles in fittings. Be sure the whole frame, including the 1' set backs, are assembled before installing the net.
3. To install netting hook and fasten bungee cords evenly along sides and top of the frame. Evenly space and tighten down the 20 adjustable straps along the bottom of the netting.
4. Attach vinyl skirt at bottom using ty-raps. Thread white webbing into netting at desired location to simulate net height.