



RD-STD68BR

REDNECK 6X8 GAME CHANGER FRONT SUPPORT BRACKET ASSEMBLY INSTRUCTIONS

**6x8 BLIND CANNOT BE TIPPED UP LIKE OTHER BLINDS. BLIND
MUST BE PLACED ON TOP OF THE STAND AFTER STAND IS
ERECTED AND SECURED TO THE GROUND.**


READ THESE INSTRUCTIONS IN THEIR ENTIRETY PRIOR TO ASSEMBLING THIS PRODUCT

WARNING! Do not remove, modify and/or omit any portion or otherwise mechanically modify this product(s) or its assemblies in any manner. Modification, misuse and/or part substitution shall immediately void your factory warranty. If you suspect that a part(s) is missing and/or defective, immediately discontinue all use of the product and contact Redneck Outdoor Products at 877-523-9986 for replacement of missing or defective parts.


NOTE: Some parts of this product are manufactured to be universal in use, so there may be some parts containing holes that will not be used in the assembly of this particular model. To minimize confusion in the assembly process, please read these instructions in their entirety before beginning.

Should you have any questions about the assembly, installation or use of this product, or any other Redneck Outdoor Products, please call one of our customer service representatives toll free at 877-523-9986.



WELDED FRONT SUPPORT - AA




VERT. SUPPORT
UPPER LEFT - CC




VERT. SUPPORT
UPPER RIGHT - EE



VERT. SUPPORT
LOWER LEFT - BB




VERT. SUPPORT
LOWER RIGHT - DD



ITEM	PART	QTY
AA	WELDED FRONT SUPPORT ASSY	1
BB	VERTICAL SUPPORT - LOWER LEFT	2
CC	VERTICAL SUPPORT - UPPER LEFT	2
DD	VERTICAL SUPPORT - LOWER RIGHT	2
EE	VERTICAL SUPPORT - UPPER RIGHT	1
	3/8-16 X 2" LONG HEX BOLT	2
	3/8" WASHER 2" O.D.	2
	3/8" FLAT WASHER	2
	3/8" LOCK WASHER	2
	3/8-16 HEX NUT	2
	3/8-16 X 2.25" LONG CARRIAGE BOLT	4
	3/8-16 X 1" LONG CARRIAGE BOLT	12
	3/8-16 LOCKING FLANGE NUT	16
TOOLS REQUIRED NOT INCLUDED		
(2) 9/16" SOCKETS OR WRENCHES		
DRILL WITH 3/8" DRILL BIT		

STEP 1: With the Stand built, find the Welded Front Support AA. Slide the Front Support over the front of the stand as shown in Figure 10.1. Make sure the wider top flange is facing up as shown in Figure 10.2. Once the Support is pushed all the way in place the cross bar should hit with the front of the stand. With the Support in place secure it with a 3/8" x 2.25" long carriage bolt, you will use one of the (2) holes as shown in Figure 10.2. If your stand has a channel across the front you will use the farther one and if your stand has a tube at the end of it you will use the closer one. Install the bolt going from the top down and secure on the bottom side with a 3/8" flange nut finger tight. Do this on both sides to keep in place during assembly.



3/8" CARRIAGE BOLT 2.25" LONG




FIGURE 10.2

STEP 2: Find the (4) Vertical Supports, there will be uppers, lowers and left and rights. Connect the upper and lower sections together with the (8) 3/8-16 x .1" Carriage Bolts as shown in Figure 11.2. There will be (4) bolts on each Vertical Support. With the flange on the outside, place the bottom of the porch support behind the top perimeter rail, see Figure 11.3. With the bottom of the Porch Support attached, secure the top of the porch support with the 2.25" carriage bolt as shown in Figure 11.4. Repeat these steps for the other side. Once everything is in place tighten down all the bolts.




FIGURE 11.2

FIGURE 11.3

FIGURE 11.4

FIGURE 11.1

STEP3: Once the stand is built and secured in place, and the blind is placed on top of the stand. Bolt the (4) bolts in place as instructed in the stand instructions. Once the stand is fastened to the stand locate the slots in the front of the 6x8 Support, as shown in Figure 12.2. Take your drill and 3/8" drill bit and drill through the bottom of the floor up through the top of the floor, making sure to stay centered between the slot. Once both holes are drilled, insert the 3/8" bolt and large washer down trough the floor. Secure on the bottom side of the stand with the 3/8" washer, lock washer and nut. Once both are in place make sure to tighten the bolts, making sure not to over tighten.




FIGURE 12.1

FIGURE 12.2