



8" & 12" Corner Shelf Install Guide



Tools/Supplies:


- Level
- Caulking Gun
- Drill
- Pencil
- Silicone
- Drill Bit
- Painter's Tape
- Caulk
- Phillip's Head Screwdriver
- Sponge
- Clean Cloth
- Fine Grit Sandpaper

- 1) Thoroughly clean the surface on which the shelf will be adhered.
- 2) Plan height for installation of the shelf. Dry fit the shelf and sand the back edge as needed to allow for a good fit.
- 3) You can install the shelf with silicone or the screws included:
 - a) **Silicone Installation:** Apply silicone to the back edge of shelf and press firmly in place applying even pressure. You may use painter's tape to help hold it in place while it dries. Allow to dry for 24 hours.
 - b) **Screw Installation:** First, place your shelf in desired location. Use a pencil to mark the mounting holes. Next, drill out the pilot holes. Insert the anchor through pilot holes, apply silicone to back edge of shelf and then screw shelf to wall.
- 4) Once silicone has fully cured, apply a bead of silicone caulk around the perimeter of the shelf to seal out water. Use a wet finger to smooth the caulk and then clean off excess with a damp sponge.
- 5) Allow to fully dry before use.

HELPFUL HINTS :

- When figuring out the "proper" height for your shelf, it's a good idea to consider everyone that will use the shower.
- Periodically check the silicone and caulk for any wear or deterioration and correct as necessary.

Soap Dish Install Guide



Tools/Supplies:

- Level
- Caulking Gun
- Silicone
- Pencil
- Painter's Tape
- Caulk
- Sponge/Clean Cloth
- Fine Grit Sandpaper

- 1) Thoroughly clean the surface on which the soap dish will be adhered.
- 2) Plan height for installation of the dish. Dry fit the soap dish and the back as needed to allow for a good fit.
- 3) You can install the soap dish with silicone.
- 4) **Silicone Installation:** Apply silicone to the back of the soap dish and press firmly in place applying even pressure. You may use painter's tape to help hold it in place while it dries. Allow to dry for 24 hours.
- 5) Once silicone has fully cured, apply a bead of silicone caulk around the perimeter of the soap dish to seal out water. Use a wet finger to smooth the caulk and then clean off excess with a damp sponge.
- 6) Allow to fully dry before use.

HELPFUL HINTS :

- When figuring out the "proper" height for your soap dish, it's a good idea to consider everyone that will use the shower.
- Periodically check the silicone and caulk for any wear or deterioration and correct as necessary.