
#### F5707-XX Drain Installation



# II IMPORTANT II

### SILICONE, not Plumber's Putty! diw bəllətəni əd nibyb ədt tadt bəbnəmmosəy zi tl

(.1 %) egnal-1 niard ent to ebizrebnu ent no bead a bring short from the drain of the drain threads and a bead on the Disassemble the F5714-XX drain assembly, apply a liberal amount of "kitchen and bath" type silicone

cleaned while silicone is wet. dry cloth. Clean well for it will be very difficult to clean silicone residue from the inside of bathtub if not inside the bathub to stop the drain from spining.) Wipe off any excess silicone around the drain with a wrench tighten the drain nut until firmly to rubber gasket and the botom of bathtub (holding the pliers Drain securely into the drain Nut and flex connector. Once the flex connector is tight, using a monkey nut and 5714 Flex Line at the same time. Using the handles of a pair of pliers can help you screw the Flex Line (#4). Place threaded part of flex connector below nut, you will screw the drain flange into the tighten untill you see one or two threads below the nut. Apply silicone to the inside threads of 57 14of flat rubber gasket. Now by hand, loosely screw (#3) Drain Nut onto the (#1) Drain Flange, only the flat rubber onto the drain threads to the bottom of bathtub, apply silicone on now exposed face and threads of drain flange. Find the flat rubber gasket (#2) disregard the tapered rubber gasket. Push Insert the drain flange through the drain hole, apply silicone onto bottom of bathub around the drain

### Safety Instructions

- unless they are closely supervised by an adult at all times. ■ DANGER! To reduce the risk of injury, do not permit children to use bathtubs
- Do not use attachments not recommended by the manufacturer. Use this bathtub only for its intended use as described in this manual.
- near a filled tub. while in or near a filled bathtub. Never use or handle electrical devices while in or Do not attempt to plug in or unplug the electrical devices (including the bathtub)
- Never drop or insert any objects into any openings.
- children. The water temperature in a bathtub should never exceed 104°F (40°C). considered safe for longer durations (exceeding 10 - 15 minutes) or for young between 100° and 104°F (38°- 40°C). Any temperature below 100°F is Only healthy adults should use the bathtub when the water temperature is
- should limit bathtub temperatures to 38°C (100°F). during the early months of pregnancy. Pregnant or possibly pregnant women Excessive water temperatures have a high potential for causing fetal damage
- unconsciousness and the possibility of drowning. ■ The use of alcohol, drugs, or medications before or during bathing may lead to
- physician before using this bathtub. consult a physician before using. Persons using medications should consult a disease, low or high blood pressure, circulatory problems, or diabetes should pressure. Persons suffering from obesity, who have a medical history of heart Use of this bathtub may cause drowsiness and changes in heart rate and/or blood

forbidden. Trademarks and trade names used in this document refer to either the entities claiming the marks and ames or their products. American Bath Factory disclaims any proprietary interest in trademarks and trade names other than reserved. Reproduction in any manner whatsoever without the written permission of American Bath Factory is strictly Information in this document is subject to change without notice. Copyright 2016, American Bath Factory. All rights

# Installing a Euro Style Bathtub



overflow if desired. American Bath Factory Modern Bathtub comes without an overflow, you may order one with an Free Standing Bathtubs WITHOUT OVERFLOW

to disinfect or cover ventilation holes to contain the hazard of venting of bacteria. problem of having surface areas where water containing bacteria can accumulate and there is no ability ADILIOM Section P2720.4 instructions. American Society of Mechanical Engineers recognizes the Take or yldmos of the confilm or also Whirlpool Bathtub appliances are to comply to ASME overflows was eliminated because due to lack of use it was resulting in growth of bacteria and ICP, International Plumbing Code book 2009 discusses the fact that the past standard of required

#### Floor Drain Is Recommended

This will help for any bathroom water overflow or leaks from bathtubs, toilets, sinks or broken water the bath or while easing into the bathtub. This is why it is safe to only have a 2" floor drain installed. on or the rapid entry into the barhub, they are designed to help while adding additional water to heat rapid increase of water height. Most overflows do not prevent water overflow from faucets being left overflow allows for extra soaking depth, but precaution is needed when entering the bathtub, due to American Bath Factory Freestanding Bathtubs are designed for maximum soaking depth. Having no

and overflow. (Unfortunately the aesthetics will be less appealing and installation more difficult.) equipped with an exposed overflow. We will modify any bathtub to accommodate an exposed waste exposed 5713 drain); or you can contact American Bath Factory before shipping to have your bathtub and is still requiring an overflow, an overflow can be drilled upon request. (Order and install an Check your local codes, some cities still have old or outdated requirements. If your city is unchanging Check your Local City Codes



ALIGN & SECURE YOUR BATHTUB

duthtad salt of 19thw gailbba. Allow 24 hours for the Silicone to cure completely before

test is complete and there are no leaks, proceed with next steps. If everything is sealed and dry, fill your bathtub 3/4 of the way and check for leaks. After the water

#### **duthing Your Bathtub**

main drain line (anywhere under the bathtub inside the base, at least 3" from the drain.) bathtub base as marked on the floor. You will use the drain location to determine where to bring in the bathtub, measure and mark the drain position. The drain should be 3" from the end of outside edge of on the floor. Check level, using rubber spacers if need be to stop any movement or rocking. Move the Position your bathtub into desired installed location. Using a dry ersable marker mark bathtub position

#### Faucet Installation

install your bathtub to the main drain pipe. faucet. Follow the faucet installtion instructions. It may be more practical to install the faucet before you Faucets do not install directly onto Euro freestanding bathtubs, you may use a wall mount or floor mount

easy. Just make sure you have a trap for water to stop deadly fumes coming up the drain. The 5774-Flex line can bend and expand up to 2 feet, this will make conecting to your main drain very possible to bend the 5714-Flex into a p-Trap shape and connect directly into a fitting like (#6) 95K. 5714-Flex Line. It is safer to use a rigid P-trap like the (#5) 400EK shown in diagram in step 4. It is will need to determine what fittings will be needed to connect to the 1 J/2' plastic pipe end of the There are many different directions and sizes the main drain supply will attach to the drain, your installer

#### Securing Bathtub to the floor

from the tile and tub with a rag and water. hold the bathtub in place. Apply the caulk slowly and only about 2 feet at a time. Wipe the excess around the base of the bathtub. Apply a bead of caulk around the base of the bathtub; this helps to American Bath Factory's recommended method for securing your bathtub to the floor is to use caulk (Nonday thru Friday, 7:15 am - 4:00 pm (PST) or email us at info©americanbathfactory.com


We would like to take this opportunity to thank you for your purchase of this American Bath Factory Bathtub. Should you have any questions or feedback about your new bathtub, please call us toll-free at


HTA8-424 (008)




installation/user guide

### **SPECIFICATIONS**







MADISA HTA8

#### americanbathfactory.com

13405 Estelle Street, Corona, California 92879 Phone 800.454.BATH Fax 951.734.1480

If you should dull, scratches and dulling can be removed with a liquid polish such as original look. Scratches and dulling can be removed with a liquid polish such as Gel-Gloss. Deep scratches or burns can be removed by using very fine sandpaper (600 grit or higher) and finished with a liquid polish

# USE OF THESE CHEMICALS WILL VOID YOUR WARRANTY

or other chemicals that attack the structural integrity of plastic (including, but not limited to acetones). Use of these chemicals will destroy the acrylic surface of your bathtub.

DO NOT CLEAN YOUR BATHTUB WITH GOOF OFF', SCRUBBING BUBBLES', LYSOL BATHROOM CLEANER', PINE-SOL', WHITE-CAP', LES TOLL', PAINT THINNER', MEK.

TNATAO9MI

and SPIC & SPAN POWDER"

Your bathtub's surface is very easy to clean. There are no pores for dirt to penetrate, so dirt will just rinse off with water. For sanitary purposes, you should occasionally clean your bathtub with non-abrasive soap and water when possible. Avoid harsh that is required. If you spill something on the bathtub and need a stronger cleaner, that is required. If you spill something on the bathtub and need a stronger cleaner, the following are SAFE to use: GEL GLOSS, TACKLE, TOP JOB', FORMULA 409°, that is required. If you spill something on the bathtub and need a stronger cleaner, and with the following are SAFE to use: GEL GLOSS, TACKLE, TOP JOB', FORMULA 409°, the following are SAFE to use: GEL GLOSS, TACKLE, TOP JOB', FORMULA 409°, and the following are SAFE to use of the sanitary of the s

## Cleaning & Maintaining your Bathtub

1

#### Before You Begin

To ensure that no damage has occurred to your bathtub during shipping, it is important to check your bathtub for damage prior to the installation in your home!

2

#### **Drain Assembly for Freestanding Bathtub**

1) American Bath Factory provides the Euro Drain Assembly (F5707-XX) seen below, depending on your main drain pipe configuration your installer will need to provide the connection fittings to connect between your main drain and our drain assembly. Lowes Home Improvement center's carry a large variety of connections needed. Most commonly used is Keeney Manufacturing fitting 400BK and 95K this is a 1 1/2" P-Trap and connection fitting seen below.

