



Launcher 200 Instructions



Model No.: SRL20020210216R

Dear customer,

Thank you for buying Andjoor Launcher 200 Sports Ramp, This introduction will help you to properly install and use your Launcher 200.

Please read these carefully before using and keep them for future reference.

If you require further assistance, please contact our online customer service by search for our brand: "Andjoor" on FaceBook to get a quick response.

We wish you a lot of fun with your new Launcher!

BENEFITS

- ✗ Andjoor Sports Ramps series are made of high-quality wood with multi-layer anti-skid boards, which are great for use as sports ramps.
- ✗ Good take-off angle, non-slip, wider, longer, and stable, with a load capacity of up to 450 pounds.
- ✗ The Andjoor Launcher 200 has bolt-on components perfect for practicing skateboarding, biking, skiing, roller skates, and mountain bike skills and techniques.
- ✗ It can easily be taken to the park and worn as a rucksack by using the slots and strap provided.


CAUTION

- ✗ The ramp should always be unfolded by an adult especially for young children to avoid finger entrapment in the hinge zone.
- ✗ Before heading out to jump you should always check the security of all fixings and inspect the ramp for damage that may compromise its strength.
- ✗ Make sure the batten is fully located in place and undamaged before jumping off this ramp.
- ✗ Make sure the ramp is suitably located for your ability level, it should always be placed on an even surface with all points in contact with the ground.
- ✗ Placing the ramps on grass will provide a softer impact surface and a partner or spectator will look after you if a jump goes wrong and you need help.
- ✗ We always recommend using a tabletop to fill the gap which makes transfers from takeoff ramp to landing ramps safer.
- ✗ For maximum fun and safety and enjoyment, please wear a helmet preferably a full-face helmet and at least knee pads elbow pads and gloves.
- ✗ Always work up ramp sizes gaining confidence before attempting bigger ramps bigger air or bigger gap jumps.

MAINTENANCE

- ✗ The ramp should not be left outside and should be stored dry inside.
- ✗ We recommend treating your ramp with preservative before use and at least annually.

PACKAGE CONTENTS



x 1



x 1



x 1



x 1

HOW TO INSTALL


- ✗ Place the batten into the slots in each leg.
- ✗ The tag should face outwards.
- ✗ A firm push should locate the legs.



✗ It is important to note that when removing the batten an equal pull should be exercised on both sides and at the same time to avoid locking the batten in place. This could permanently damage a ramp if it were to Jam on one leg.

RUCKSACK MOOD

- ※The batten is best located on the back face of the ramp is being carried in a rucksack mood.
- ※The strap can be used to prevent the ramp legs from opening and also secure the batten to the ramp.
- ※Please follow the Instruction pictures which show how easy these shoulder straps can be adjusted.



WARRANTY

※Andjoo Launcher 200 Sports Ramp is under Andjoo's warranty. If the product has any manufacturing defect, please contact customer service via Messenger by search for our brand: "Andjoo" on Facebook to get a quick response, or Email(service@andjoo.com) with your order number and other details to the problem. We will send you further information about the return or exchange.

Register your product

※Register your product for warranty and endless possibilities by search for our Brand: "Andjoo" on Facebook, send us a message and get a quick response.

You are now ready to go to find
a safe place to practice jumping! !

