


YOU WILL NEED:





Step Three:

Once the water has boiled, grind your whole bean coffee to a coarse consistency.

Add ground coffee to the French Press at 1 heaping teaspoon per 5 ounces of water.









Step Four:

Pour desired volume of boiled water over coffee grounds slowly.

Optionally, you can stir the water and grounds.



Step Five:

Return the Lid and Plunger to your French Press and ensure that the plunger pushes an inch or two into the boiled water.



5 Step Six:

Wait 2-4 minutes depending on the volume of water used, longer for more water, or wait longer for stronger coffee.



Step Seven:

Slowly press the plunger into the water, ensuring that the plunger stays vertical to avoid letting coffee grounds through the sides.



Step Eight:

Give the coffee a moment for any loose coffee grounds to settle and open the pour spout on your French Press.

DO NOT remove the lid or pull the plunger back up.



Step Nine:

Pour yourself an excellent cup of French Press brewed coffee and enjoy!

