



## Feiyu SCORP Pro Lens Compatibility List

Brand	Camera Model	Camera Size	Lens Model	Lens size & weight	Mounting status	Balance adjustment (install horizontal)		Balance adjustment (install vertical)		Installation Remark	
						Short End	Long End	Short End	Long End		
Sony		a1 128.9×96.9×80.8mm 652g a9 126.9×95.6×63.0mm 588g a9 II 128.9×96.4×77.5mm 678g a7 III (A7M3) 126.9×95.6×73.7mm 565g a7R 126.9×94.4×48.2mm 407g a7R III 126.9×95.6×62.7mm 572g a7S 126.9×94.4×48.2mm 446g a7S II 126.9×95.7×60.3mm 584g a7S III 128.9×96.9×80.8mm 614g a7R2 126.9×95.7×60.3mm 582g a7M2 126.9×95.7×59.7mm 556g	E 10 - 18mm F4 OSS	Φ70mm*63.5mm 225g	Camera + Lens	✓	✓	✓	✓	Camera Riser is required to help balancing the gimbal.	
			Focus motor + Camera	✓	✓	✓	✓				
			FE 12-24mm F4 G	Φ87mm*117mm 565g	Camera + Lens	✓	✓	✓	✓		
			Focus motor + Camera	✓	✓	✓	✓				
			FE 16-35mm F2.8 GM	Φ89mm*122mm 680g	Camera + Lens	✓	✓	✓	✓		
			Focus motor + Camera	✓	✓	✓	✓				
			FE16-35mm f/4 ZA OSS	Φ78mm*99mm 518g	Camera + Lens	✓	✓	✓	✓		
			Focus motor + Camera	✓	✓	✓	✓				
			FE 24-70 F2.8 GM	Φ87.6mm*136mm 886g	Camera + Lens	✓	✓	✓	✓		
			Focus motor + Camera	✓	✓	✓	✓				
			Zeiss E 16-70 F4 OSS	Φ66.6mm*75mm 308g	Camera + Lens	✓	✓	✓	✓		
			Focus motor + Camera	✓	✓	✓	✓				
			E PZ 18 - 105mm F4 G OSS	Φ78mm*110mm 427g	Camera + Lens	✓	✓	✓	✓		
			Focus motor + Camera	✓	✓	✓	✓				
			E PZ 18 - 200mm F3.5 - 6.3 OSS LE	Φ93.2mm*99mm 649g	Camera + Lens	✓	✓	✓	✓		
			Focus motor + Camera	✓	✓	✓	✓				
			FE 4/24-105 G OSS	Φ83.4mm*113.3 mm 663g	Camera + Lens	✓	✓	✓	✓		
			Focus motor + Camera	✓	✓	✓	✓				
			FE 28-70mm f/3.5-5.6 OSS	Φ72.5mm*83mm 295g	Camera + Lens	✓	✓	✓	✓		Camera Riser is required to help balancing the gimbal.
			Focus motor + Camera	✓	✓	✓	✓				
			FE 28mm F2	Φ64mm*60mm 200g	Camera + Lens	✓	✓	✓	✓		Camera Riser is required to help balancing the gimbal.
			Focus motor + Camera	✓	✓	✓	✓				
			Zeiss FE 35mm F2.8 ZA	Φ61.5mm*36.5mm 120g	Camera + Lens	✓	✓	✓	✓		Camera Riser is required to help balancing the gimbal.
			Focus motor + Camera	✓	✓	✓	✓				
			Sigma 30mm f/1.4 DC DN	Φ64.8mm*73.3mm 265g	Camera + Lens	✓	✓	✓	✓		Camera Riser is required to help balancing the gimbal.
			Focus motor + Camera	✓	✓	✓	✓				
			Sigma 35mm f1.4 DG HSM Art	Φ77mm*94mm 665g	Camera + Lens	✓	✓	✓	✓		
			Focus motor + Camera	✓	✓	✓	✓				
			FE 55mm F1.8	Φ64mm*71mm 281g	Camera + Lens	✓	✓	✓	✓		Camera Riser is required to help balancing the gimbal.
			Focus motor + Camera	✓	✓	✓	✓				
			FE 50mm F2.8 MACRO	Φ71mm*71mm 236g	Camera + Lens	✓	✓	✓	✓		Camera Riser is required to help balancing the gimbal.
			Focus motor + Camera	✓	✓	✓	✓				
			FE 85mm F1.4 GM	Φ89.5mm*107.5mm 820g	Camera + Lens	✓	✓	✓	✓		
			Focus motor + Camera	✓	✓	✓	✓				
			Vario-Tessar FE 24-70mm F4 ZA OSS	Φ73mm*94.5mm 426g	Camera + Lens	✓	✓	✓	✓		
			Focus motor + Camera	✓	✓	✓	✓				
			FE PZ 16-35mm F4 G	Φ80.5mm*88.1mm 353g	Camera + Lens	✓	✓	✓	✓		Camera Riser is Required
			Focus motor + Camera	✓	✓	✓	✓				
			Sigma 65mm F2 DG DN Sony FE adapter	Φ72mm*74.7mm 405g	Camera + Lens	✓	✓	✓	✓		
			Focus motor + Camera	✓	✓	✓	✓				
FX3	FX3: 77.8×129.7×84.5mm 640g	TAMRON 28-75mm f/2.8 Di III RXD	Φ73.0mm*117.8mm 550g	Camera + Lens	✓	✓	✓	✓	Camera Riser is Required		
Focus motor + Camera	✓	✓	✓	✓							
A7M4	a7M4 129.0×97.0×81.0mm 699g	FE 24-240mm F3.5-6.3 OSS	Φ119*81mm 780g	Camera + Lens	✓	✓	✓	✓			
Focus motor + Camera	✓	✓	✓	✓							
FE 50mm f/1.8	Φ68.6mm*59.5mm 186g	Camera + Lens	✓	✓	✓	✓					
Focus motor + Camera	✓	✓	✓	✓							
A7R4	A7R4 128.9×96.4×77.5mm 665g	FE 24-105mm f/4 G OSS	Φ83.4*113.3mm 663g	Camera + Lens	✓	✓	✓	✓	Camera Riser is required and lens holder are required for Long end lens.		
A7RM4A	A7RM4A 128.9×96.4×77.5mm 580g	FE 28-60mm f/4-5.6	Φ67mm*45mm 167g	Camera + Lens	✓	✓	✓	✓			
Focus motor + Camera	✓	✓	✓	✓							
RX101V (RX10M4)	RX10M4 132.5×94×127.4mm 1095g	---	---	Camera + Lens	✓	✓	✓	✓	1. Camera Riser required when you install horizontally and the Long end Lens need Lens holder; 2. In vertical installation, it is best to add a quick release plate in horizontal installation and install the lens holder		
Focus motor + Camera	✓	✓	✓	✓							
FDR-AX60	FDR-AX60 73mm x 80.5mm x 173mm 535g	---	---	Camera + Lens	✓	✓	✗	✗			
Focus motor + Camera	✗	✗	✗	✗							
FDR-AX700	FDR-AX700 116×89.5×196.5mm 935g	---	---	Camera + Lens	✓	✓	✗	✗			
Focus motor + Camera	✗	✗	✗	✗							
Brand	Camera Model	Camera Size	Lens Model	Lens size & weight	Mounting status	Balance adjustment (install horizontal)		Balance adjustment (install vertical)		Installation Remark	
						Short End	Long End	Short End	Long End		
			E 10 - 18mm F4 OSS	Φ70mm*63.5mm 225g	Camera + Lens	✓	✓	✓	✓	Camera Riser is required to help balancing the gimbal.	
			FE 12-24mm F4 G	Φ87mm*117mm 565g	Focus motor + Camera	✓	✓	✓	✓		
			FE 16-35mm F2.8 GM	Φ89mm*122mm 680g	Camera + Lens	✓	✓	✓	✓		
			FE16-35mm f/4 ZA OSS	Φ78mm*99mm 518g	Focus motor + Camera	✓	✓	✓	✓		
			FE 24-70 F2.8 GM	Φ87.6mm*136mm 886g	Camera + Lens	✓	✓	✓	✓		
			Vario-Tessar FE 24-70mm F4 ZA OSS	Φ73mm*94.5mm 426g	Focus motor + Camera	✓	✓	✓	✓		



D850	D850 146×124×78.5mm 1005g	AF-S NIKKOR 24-120mm f/4E ED VR	Φ84mm*103.5mm 710g	Camera + Lens	✓	✓	✓	✓	In vertical installation, it is best to add a quick release plate in horizontal installation and install the lens holder	
				Focus motor + Camera	✓	✓	✓	✓		
Z5	Z5 134×100.5×69.5mm 675g	NIKKOR Z 50mm f/2.8	Φ74.5mm*66mm 260g	Camera + Lens	✓	✓	✓	✓		
				Focus motor + Camera	✓	✓	✓	✓	Camera Riser Required	
Z30	Z30 128 x 73.5 x 59.5mm 405g	NIKKOR Z DX 16-50mm f/3.5-5.6 VR	Φ70mm*32mm 135g	Camera + Lens	✓	✓	✓	✓		
				Focus motor + Camera	✓	✓	✗	✗	Camera Riser required	
Brand	Camera Model	Camera Size	Lens Model	Lens size & weight	Mounting status	Balance adjustment (install horizontally)		Balance adjustment (install vertical)		Installation Remark
						Short End	Long End	Short End	Long End	
EOS R EOS RP EOS R6	EOS R 135.8×98.3×84.4mm 660g EOS RP 132.5×85×70mm 485g EOS R6 138.4×97.5×88.4mm 598g		RF 35mm F1.8 MACRO IS STM	Φ74.4mm*62.8mm 305g	Camera + Lens	✓	✓	✓	✓	
					Focus motor + Camera	✓	✓	✓	✓	
			EF-S 18-200mm f/3.5-5.6 IS	Φ78.6mm*102mm 595g	Camera + Lens	✓	✓	✓	✓	
					Focus motor + Camera	✓	✓	✓	✓	
			EF 50mm f/1.4 DG HSM Art	Φ85mm*100mm 815g	Camera + Lens	✓	✓	✓	✓	
					Focus motor + Camera	✓	✓	✓	✓	
			EF 17-40mm f/4L USM	Φ83.5mm*96.8mm 475g	Camera + Lens	✓	✓	✓	✓	
					Focus motor + Camera	✓	✓	✓	✓	
			RF 50mm F1.2L USM	Φ89.8mm*108mm 950g	Camera + Lens	✓	✓	✓	✓	
					Focus motor + Camera	✓	✓	✓	✓	
			RF 28-70mm F2L USM	Φ103.8mm*139.8mm 1430g	Camera + Lens	✓	✓	✓	✓	
					Focus motor + Camera	✓	✓	✓	✓	
			RF 24-105mm F4L IS USM	Φ83.5mm*107.3mm 670g	Camera + Lens	✓	✓	✓	✓	
		Focus motor + Camera	✓	✓	✓	✓				
RF 15-35mm F2.8 L IS USM	Φ88.5mm*126.8mm 840g	Camera + Lens	✓	✓	✓	✓				
		Focus motor + Camera	✓	✓	✓	✓				
RF50mm F1.8 STM	Φ69.2mm*40.5mm 160g	Camera + Lens	✓	✓	✓	✓				
		Focus motor + Camera	✓	✓	✗	✗				
RF85mm F2 MACRO IS STM	Φ78mm*90.5mm 500g	Camera + Lens	✓	✓	✓	✓				
		Focus motor + Camera	✓	✓	✓	✓	Camera Riser is required			
RF-S18-45mm F4.5-6.3 IS STM	Φ69mm*44.3mm 130g	Camera + Lens	✓	✓	✓	✓				
		Focus motor + Camera	✓	✓	✗	✗				
RF15-30mm F4.5-6.3 IS STM	Φ76.6mm*88.4mm 390g	Camera + Lens	✓	✓	✓	✓				
		Focus motor + Camera	✓	✓	✗	✗	Camera Riser is required			
EOS 80D	EOS 80D 139×105.2×78.5mm 730g	EF-S 18-200mm f/3.5-5.6 IS	Φ78.6mm*102mm 595g	Camera + Lens	✓	✓	✓	✓		
				Focus motor + Camera	✓	✓	✓	✓		
EOS 6D Mark II	6D Mark II 144×110.5×74.8mm 765g	EF 24-70mm f/4L IS USM	Φ83.4mm*93mm 600g	Camera + Lens	✓	✓	✓	✓		
				Focus motor + Camera	✓	✓	✓	✓		
EOS 6D	EOS 6D 144.5×110.5×71.2mm 750g	16-35mm f/2.8L II USM	Φ88.5mm*111.6mm 635g	Camera + Lens	✓	✓	✓	✓		
				Focus motor + Camera	✓	✓	✓	✓		
		EF-S 18-200mm f/3.5-5.6 IS	Φ78.6mm*102mm 595g	Camera + Lens	✓	✓	✓	✓		
				Focus motor + Camera	✓	✓	✓	✓		
		EF 24-105mm f/4L IS USM	Φ83.5mm*107mm 670g	Camera + Lens	✓	✓	✓	✓		
				Focus motor + Camera	✓	✓	✓	✓		
EOS 200D II (250D)	EOS 200D II 122.4×92.6×69.8mm 456g	EF-S18-55mm f/4-5.6 IS STM	Φ66.5mm*61.8mm 215g	Camera + Lens	✓	✓	✓	✓		
				Focus motor + Camera	✓	✓	✓	✓		
EOS 5D Mark IV	5D Mark IV 150.7×116.4×75.9mm 890g	EF 24-105mm f/4L IS USM	Φ83.5mm*107mm 670g	Camera + Lens	✓	✓	✓	✓		
				Focus motor + Camera	✓	✓	✓	✓		
EOS 5D Mark III EOS 5DS R	5D Mark III 152×116.4×76.4mm 950g 5DS R 152×116.4×76.4mm 930g	EF 24-105mm f/4L IS USM	Φ83.5mm*107mm 670g	Camera + Lens	✓	✓	✓	✓		
				Focus motor + Camera	✓	✓	✓	✓		
		EF 24-105 mm f/4L IS II USM	Φ88.5mm *127.5mm 795g	Camera + Lens	✓	✓	✓	✓		
				Focus motor + Camera	✓	✓	✓	✓		
		EF 24-70mm f/2.8L II USM	Φ88.5mm*113mm 805g	Camera + Lens	✓	✓	✓	✓		
				Focus motor + Camera	✓	✓	✓	✓		
		16-35mm f/2.8L II USM	Φ88.5mm*111.6mm 635g	Camera + Lens	✓	✓	✓	✓		
				Focus motor + Camera	✓	✓	✓	✓		
EOS 70D	EOS 70D 139×104.3×78.5mm 755g	16-35mm f/2.8L II USM	Φ88.5mm*111.6mm 635g	Camera + Lens	✓	✓	✓	✓		
				Focus motor + Camera	✓	✓	✓	✓		
EOS 77D	EOS 77D 131×99.9×76.2mm 540g	EF 24-70mm f/4L IS USM	Φ83.4mm*93mm 600g	Camera + Lens	✓	✓	✓	✓		
				Focus motor + Camera	✓	✓	✓	✓		
EOS M50	M50 116.3×88.1×58.7mm 390g	EF-M 15-45mm F3.5-6.3 IS	Φ60.9mm*44.5mm 130g	Camera + Lens	✓	✓	✓	✓	Camera Riser is required to help balancing the gimbal.	
				Focus motor + Camera	✓	✓	✓	✓		
EOS M50 Mark II	EOS M50 Mark II 116.3×88.1×58.7mm 388g	EF-M 15-45mm f/3.5-6.3 IS STM	Φ60.9mm*44.5mm 130g	Camera + Lens	✓	✓	✗	✗		
				Focus motor + Camera	✗	✗	✗	✗		
PowerShot G7 X Mark III	G7 X Mark III 105.0×60.9×41.4mm 304g	—	—	Camera + Lens	✓	✓	✗	✗		
				Focus motor + Camera	✓	✓	✗	✗		
EOS 850D	EOS 850D 131×102.6×76.2mm 515g	EF-S 18-55mm f/4-5.6 IS STM	Φ66.5mm*61.8mm 215g	Camera + Lens	✓	✓	✓	✓	Camera Riser is required to help balancing the gimbal.	
				Focus motor + Camera	✓	✓	✓	✓		
EOS-1D X Mark III	1D X Mark III 158×167.6×82.6mm 1250g	CANON EF 70-200mm f/2.8L IS III USM	Φ88.8mm*199mm 1480g	Camera + Lens	✓	✓	✓	✓		
				Focus motor + Camera	✓	✓	✓	✓		
EOS 90D	EOS 90D 140.7×104.8×76.8mm 701g	EF-S 18-135mm f/3.5-5.6 IS USM	Φ77.4mm*96mm 515g	Camera + Lens	✓	✓	✓	✓		
				Focus motor + Camera	✓	✓	✓	✓	Camera Riser is required	
EOS R3	EOS R3 150×142.6×87.2mm 1015g	RF28-70mm F2 L USM	Φ103.8mm*139.8mm 1430g	Camera + Lens	✓	✓	✓	✓	Lens holder is required. Because the camera is relatively heavy, vertical installation needs to be more careful, so that the quick release plate contact more camera, fixing screws as tight as possible, carefully leveling.	
				Focus motor + Camera	✓	✓	✓	✓	Consider buying an extra quick mounting plate and using two support racks to support the camera	

EOS R5C EOS R5	EOS R5C 142×101×111mm 680g EOS R5 138.5×97.5×88mm 738g	RF14-35mm F4 L IS USM	Φ84.1mm*99.8mm 540g	Camera + Lens	✓	✓	✓	✓	Camera Riser and lens holder are required, no need to remove the viewfinder's protector		
				Focus motor + Camera	✓	✓	✓	✓			
EOS M6 Mark II	EOS M6 Mark II 119.6×70×49.2mm 408g	EF-M 15-45mm f/3.5-6.3 IS STM	Φ60.9mm*44.5mm 130g	Camera + Lens	✓	✓	✓	✓	Camera Riser is required		
				Focus motor + Camera	✓	✓	✓	✓			
EOS R7	EOS R7 132×90.4×91.7mm 612g	RF-S18-150mm F3.5-6.3 IS STM	Φ69mm*84.5mm 310g	Camera + Lens	✓	✓	✗	✗	Camera Riser is required		
				Focus motor + Camera	✓	✓	✗	✗			
		RF35mm F1.8 MACRO IS STM	Φ74.4mm*62.8mm 305g	Camera + Lens	✓	✓	✓	✓			
				Focus motor + Camera	✓	✓	✗	✗			
		RF-S18-45mm F4.5-6.3 IS STM	Φ69mm*44.3 130g	Camera + Lens	✓	✓	✓	✓			
				Focus motor + Camera	✓	✓	✗	✗			
RF 14-35mm f/4 L IS USM	Φ84.1mm*99.8mm 540g	Camera + Lens	✓	✓	✓	✓					
		Focus motor + Camera	✓	✓	✓	✓					
EOS R10	EOS R10 122.5×87.8×83.4mm 429g	RF-S18-150mm F3.5-6.3 IS STM	Φ69mm*84.5mm 310g	Camera + Lens	✓	✓	✗	✗	Camera Riser is required		
				Focus motor + Camera	✓	✓	✗	✗			
		RF35mm F1.8 MACRO IS STM	Φ74.4mm*62.8mm 305g	Camera + Lens	✓	✓	✓	✓			
				Focus motor + Camera	✓	✓	✗	✗			
		RF-S18-45mm F4.5-6.3 IS STM	Φ69mm*44.3 130g	Camera + Lens	✓	✓	✗	✗			
				Focus motor + Camera	✓	✓	✗	✗			
RF 14-35mm f/4 L IS USM	Φ84.1mm*99.8mm 540g	Camera + Lens	✓	✓	✓	✓					
		Focus motor + Camera	✓	✓	✗	✗					
RF85mm F2 MACRO IS STM	Φ78mm*90.5mm 500g	Camera + Lens	✓	✓	✓	✓					
		Focus motor + Camera	✓	✓	✗	✗					
EOS R8	EOS R8 132.5×86.1×70mm 461g	RF24-50mm F4.5-6.3 IS STM	Φ69.6mm*58mm 210g	Camera + Lens	✓	✓	✓	✓	Camera Riser is required		
EOS R50	EOS R50 116.3×85.5×68.8mm 376g	RF-S18-45mm F4.5-6.3 IS STM	Φ69mm*44.3mm 130g	Camera + Lens	✓	✓	✓	✓	Camera Riser is required		
EOS R6 Mark II	EOS R6 Mark II 138.4×98.4×88.4mm 670g	RF24mm F1.8 MACRO IS STM	Φ74.4×63.1mm 270g	Camera + Lens	✓	✓	✓	✓			
Brand	Camera Model	Camera Size	Lens Model	Lens size & weight	Mounting status	Balance adjustment (install horizontally)		Balance adjustment (install vertical)		Installation Remark	
						Short End	Long End	Short End	Long End		
X-T2 X-T3 X-T4	X-T2 133×92×49mm 457g X-T3 132.5×92.8×58.8mm 539g X-T4 134.6×92.8×63.8mm 607g	XF 16mm 1:1.4 R WR	Φ73mm*73mm 375g	Camera + Lens	✓	✓	✓	✓	Camera Riser is required to help balancing the gimbal.		
				Focus motor + Camera	✓	✓	✓	✓			
				XF 23mm 1:1.4 R	Φ72mm*63mm 300g	Camera + Lens	✓	✓		✓	✓
						Focus motor + Camera	✓	✓		✓	✓
				XF 35mm 1:1.4	Φ65mm*54.9mm 187g	Camera + Lens	✓	✓		✓	✓
						Focus motor + Camera	✓	✓		✓	✓
				XF 10-24mm f/4.0 R OIS	Φ78mm*87mm 410g	Camera + Lens	✓	✓		✓	✓
						Focus motor + Camera	✓	✓		✓	✓
				XF 16-55mm 1: 2.8 R LM WR	Φ83.3mm*106.0mm 655g	Camera + Lens	✓	✓		✓	✓
						Focus motor + Camera	✓	✓		✓	✓
				XF 18-55mm 1:2.8-4 R OIS	Φ65mm*70.4mm 310g	Camera + Lens	✓	✓		✓	✓
						Focus motor + Camera	✓	✓		✓	✓
XF 18-135mm f/3.5-5.6 R LM OIS WR	Φ76mm*98mm 490g	Camera + Lens	✓	✓	✓	✓					
		Focus motor + Camera	✓	✓	✓	✓					
X-H1	X-H1 139.8×97.3×85.5mm 673g	XF 16mm 1:1.4 R WR	Φ73mm*73mm 375g	Camera + Lens	✓	✓	✓	✓			
				Focus motor + Camera	✓	✓	✓	✓			
		XF 23mm 1:1.4 R	Φ72mm*63mm 300g	Camera + Lens	✓	✓	✓	✓			
				Focus motor + Camera	✓	✓	✓	✓			
		XF 35mm 1:1.4	Φ65mm*54.9mm 187g	Camera + Lens	✓	✓	✓	✓			
				Focus motor + Camera	✓	✓	✓	✓			
		XF 10-24mm f/4.0 R OIS	Φ78mm*87mm 410g	Camera + Lens	✓	✓	✓	✓			
				Focus motor + Camera	✓	✓	✓	✓			
XF 16-55mm 1: 2.8 R LM WR	Φ83.3mm*106.0mm 655g	Camera + Lens	✓	✓	✓	✓					
		Focus motor + Camera	✓	✓	✓	✓					
XF 18-55mm 1:2.8-4 R OIS	Φ65mm*70.4mm 310g	Camera + Lens	✓	✓	✓	✓					
		Focus motor + Camera	✓	✓	✓	✓					
XF 18-135mm f/3.5-5.6 R LM OIS WR	Φ76mm*98mm 490g	Camera + Lens	✓	✓	✓	✓					
		Focus motor + Camera	✓	✓	✓	✓					
X-S10	X-S10 126×85.1×65.4mm 465g	XC 15-45mm f/3.5-5.6 OIS PZ	Φ62.6mm*65.2mm 135g	Camera + Lens	✓	✓	✓	✓	Camera Riser Required		
X-A5 X-A7	X-A5 116.9×67.7×40.4mm 361g X-A7 119×67.7×41.1mm 320g	XC 15-45mm f/3.5-5.6 OIS PZ	Φ62.6mm*65.2mm 135g	Camera + Lens	✓	✓	✓	✓	Camera Riser Required		
				Focus motor + Camera	✓	✓	✓	✓			
X-T30 II	X-T30 II 118×83×47mm 383g	XC 15-45mm f/3.5-5.6 OIS PZ	Φ62.6mm*65.2mm 135g	Camera + Lens	✓	✓	✓	✓	Camera Riser Required		
X-E3	X-E3 121.3×42.7×73.9mm 337g	XF18-55mm F2.8-4 R LM O1	Φ65mm*70.4mm 310g	Camera + Lens	✓	✓	✓	✓			
				Focus motor + Camera	✓	✓	✗	✗			
X100V	X100V 128×74.8×53.3mm 478g	Kit Lens	—	Camera + Lens	✓	✓	✓	✓	The lens is too short to have a focus motor		
GFX 100S	GFX 100S 150×104.2×87.2mm 900g	GF 32-64mm f/4R LM WR	Φ92.6mm*145.5mm 875g	Camera + Lens	✓	✓	✓	✓	Camera Riser is Required		
				Focus motor + Camera	✓	✓	✓	✓			

X-T20 X-T30 X-T100 X-T200	X-T20 118.4×82.8×41.4mm 383g X-T30 118.4×82.8×46.8mm 383g X-T100 121.0×83.0×47.4mm 448g X-T200 121.0×83.7×55.1mm 370g	XF 16mm 1:1.4 R WR	Φ73mm*73mm 375g	Camera + Lens	✓	✓	✓	✓		
				Focus motor + Camera	✓	✓	✓	✓		
		XF 23mm 1:1.4 R	Φ72mm*63mm 300g	Camera + Lens	✓	✓	✓	✓		
				Focus motor + Camera	✓	✓	✓	✓		
		XF 35mm 1:1.4	Φ65mm*54.9mm 187g	Camera + Lens	✓	✓	✓	✓	Camera Riser is required to help balancing the gimbal.	
				Focus motor + Camera	✓	✓	✓	✓		
		XF 10-24mm f/4.0 R OIS	Φ78mm*87mm 410g	Camera + Lens	✓	✓	✓	✓		
				Focus motor + Camera	✓	✓	✓	✓		
		XC 16-50mm f/3.5-5.6 OIS	Φ62.6mm*65.2mm 195g	Camera + Lens	✓	✓	✓	✓	Camera Riser is required to help balancing the gimbal.	
				Focus motor + Camera	✓	✓	✓	✓		
		XF 16-55mm 1: 2.8 R LM WR	Φ83.3mm x 106.0mm 655g	Camera + Lens	✓	✓	✓	✓		
				Focus motor + Camera	✓	✓	✓	✓		
XF 18-55mm 1:2.8-4 R OIS	Φ65mm*70.4mm 310g	Camera + Lens	✓	✓	✓	✓				
		Focus motor + Camera	✓	✓	✓	✓				
XF 18-135mm f/3.5-5.6 R LM OIS WR	Φ76mm*98mm 490g	Camera + Lens	✓	✓	✓	✓				
		Focus motor + Camera	✓	✓	✓	✓				
XC 15-45mm 1:3.5-5.6 OIS PZ	Φ62.6mm*65.2mm 135g	Camera + Lens	✓	✓	✓	✓	Camera Riser is required to help balancing the gimbal.			
		Focus motor + Camera	✓	✓	✓	✓				
X-H2S	X-H2S 136.3×92.9×84.6mm 660g	XF90mmF2 R LM WR	Φ75.0mm*105mm 540g	Camera + Lens	✓	✓	✓	✓	Camera Riser Required	
X-H2	X-H2 136.3×92.9×84.6mm 660g	XF 16mm f/1.4R WR	Φ73.4mm*73.0mm 375g	Camera + Lens	✓	✓	✓	✓	Camera Riser Required	
				Focus motor + Camera	✓	✓	×	×		
X-T5	X-T5 129.5×91×63.8mm 557g	XF 8-16mm f/2.8 R LM WR	Φ88*121.5mm 808g	Camera + Lens	✓	✓	✓	✓	Camera Riser Required	
				Focus motor + Camera	✓	✓	×	×		
X-S20	X-S20 127.7×85.1×65.4mm 491g	XF18mmF1.4 R LM WR	Φ68.8*75.6mm 370g	Camera + Lens	✓	✓	✓	✓		
				Focus motor + Camera	✓	✓	×	×		Camera Riser Required
Brand	Camera Model	Camera Size	Lens Model	Lens size & weight	Mounting status	Balance adjustment (install horizontally)		Balance adjustment (install vertical)		Installation Remark
						Short End	Long End	Short End	Long End	
SIGMA	FP	FP 112.6×69.9×45.3mm 370g	panasonic LUMIX S PRO 50mm F1.4	Φ90mm*130mm 955g	Camera + Lens	✓	✓	✓	✓	Camera Riser Required
					Focus motor + Camera	✓	✓	✓	✓	
			SIGMA 45mm f/2.8 DG DN	Φ64mm*46.2mm 215g	Camera + Lens	✓	✓	✓	✓	
					Focus motor + Camera	✓	✓	×	×	
Brand	Camera Model	Camera Size	Lens Model	Lens size & weight	Mounting status	Balance adjustment (install horizontally)		Balance adjustment (install vertical)		Installation Remark
						Short End	Long End	Short End	Long End	
BMPCC	6K	180*122*94mm 1135g	CANON EF 16-35mm F2.8L II USM	Φ88.5mm*111.6mm 640g	Camera + Lens+ cage+battery	✓	✓	×	×	
					Focus motor + Camera	✓	✓	✓	✓	
	4k	178.1*96*85.5mm 722g	Olympus M. ZUIKO DIGITAL ED 12-40mm f/2.8	Φ70mm*84mm 382g	Camera + Lens	✓	✓	✓	✓	
					Focus motor + Camera	✓	✓	✓	✓	
					Focus motor +cage	✓	✓	×	×	
Notice: 1. "✓" Means Support this function. "×" Means Do not Support;										