

Mini Reces Recessed Step Light Installation Instructions



				Product Spec	cifications					
Model No.	HV3206W-SS316	HV3206W-BLK	HV3206W-WHT	HV3206N-SS316	HV3206N-BLK	HV3206N-WHT	HV3206C-SS316	HV3206C-BLK	HV3206C-WHT	
	HV3216W-SS316	HV3216W-BLK	HV3216W-WHT	HV3216N-SS316	HV3216N-BLK	HV3216N-WHT	HV3216C-SS316	HV3216C-BLK	HV3216C-WHT	
Name	Mini Reces									
Material	316 Stainless Steel	Aluminium		316 Stainless Steel	Aluminium		316 Stainless Steel	Aluminium		
Colour	Stainless Steel	Black	White	Stainless Steel	Black	White	Stainless Steel	Black	White	
IP Rating	IP67									
Input Voltage	12v DC									
Lamp Base	Built in LED									
Lamp Wattage	1x 1w									
Colour Temp		3000k		4000k			5500k			
Lumens		55lm		57lm			60lm			
CRI	>80									
Wiring	Parallel									
Dimmable	No									
Warranty		3 Years Replacement*								





Important Safety Issues:

- This product must be installed by a qualified electrician according to AS/NZS 3000.
- Ensure all electrical mains are disconnected before any installation.
- · Modification of this product will void any warranty.
- · Havit Lighting does not take responsibility for wrong installation, incorrect use, or use of installation material that does not belong to the system.
- When installing low voltage fittings, Voltage to fitting must be within +or- 5% of voltage required and cannot be installed more than 25m from LED Driver, if not within this allowance warranty will be voided.
- Aluminium and 304SS fittings must not be installed within 5km of any salt water environments.
- · All 316 stainless steel fittings must have regular cleaning maintenance to avoid any tea staining from forming on fitting. (Warranty does not cover Tea Staining)
- $\bullet \ \ \text{Aluminium and 304SS fittings must not be installed within 5km of any salt water environments.}\\$
- All o-rings and seals must be in place correctly to maintain warranty.
- · These instructions may be updated at any time due to product improvements, Please visit website for most current installation instructions.

Steps for Installation:

Contact Details:

- 1. Make sure that the electrical circuit is free of voltage (master switch off)
- 2. Make a hole where fitting is to be placed using dimensions provided on line drawings,
- 3. Using an appropriate 12v DC LED Driver DO NOT CONNECT LIGHT FITTING DIRECTLY TO 240V
- 4. If installing into concrete, insert canister making sure it is flush with wall.
- 5. Connect the cable If more than one fitting installed, wiring must be done in parallel.
- 6. Strip back the cable on both fitting and cable run and twist the positive cables together. Then connect neutral cables together
- 7. Solder all joins using solder and either a heat gun or butane gas torch.
- 8. Cover connections using an adhesive lined heat shrink or gel cap to make connection watertight. Failure to do this will void warranty.
- 9. Heat the heat shrink or crimp the gel cap making sure all connections are covered.
- 10. Insert fitting into hole or canister pushin on clips and inserting into position
- 1. If installed outside, apply silicon around edge of fitting to prevent any water from getting inside to electrical connections.
- 12. All connections must be carried out carefully, inspect all contacts before switching back on the electric circuit.

Must be installed by a licensed electrician

Warranty Terms & Conditions*

143 Beauchamp Road Tel: 02 9381 8300
Matraville NSW 2036 Fax: 02 9666 8881
Australia Email: sales@havit.com.au
Web: www.havit.com.au



