

Maro Wall Light Installation Instructions



Product Specifications				
Model No.	HV3696T-BLK-240V	HV3696T-WHT-240V	HV3696T-BLK-12V	HV3696T-WHT-12V
Name	Maro			
Material	Aluminium			
Colour	Black	White	Black	White
IP Rating	IP54		IP54	
Protection Class	1 (240v Requires Earth)		3 (Low Voltage) 🏟	
Input Voltage	240v AC		12v DC	
Lamp Base	Built in LED		Built in LED	
Lamp Wattage	6x 1w		6x 1 w	
Colour Temp	TRI Colour - 3000k, 4000k, 5500k		TRI Colour - 3000k, 4000k, 5500k	
Lumens	2x 145lm, 2x 148lm, 2x 147lm		2x 145lm, 2x 148lm, 2x 147lm	
CRI	> 80		> 80	
Wiring	Parallel		Parallel	
Dimmable	No		No	
Warranty	3 Years Replacement*		3 Years Replacement*	





- This product must be installed by a qualified electrician according to AS/NZS 3000.
- Ensure all electrical mains are disconnected before any installation.
- Modification of this product will void any warranty.
- Havit Lighting does not take responsibility for wrong installation, incorrect use, or use of installation material that does not belong to the system.
- Aluminium and 304SS fittings must not be installed within 5km of any salt water environments.
- All o-rings and seals must be in place correctly to maintain warranty
- This form may be updated at any time due to product improvements, please check online installation form for most current version.

Steps for Installation:

- Make sure that the electrical circuit is free of voltage (master switch off)
- Loosen allen screws from side of fitting.
- Remove base plate from fitting.
- Install base plate to wall in desired location using appropriate screws for application.
- Seal all holes including cable entry and around screws
- 240v Models
 - Use wire with earth; connect the earth first, then live and neutral wire.
- 12v DC Models, Use an appropriate 12v DC LED Driver **DO NOT CONNECT LIGHT FITTING DIRECTLY TO 240V -**
 - Connect Live and then neutral.
- Fitting is preset to 3000k, to change slide switch located inside base of fitting to desired colour temperature.
- Reattach fitting to base plate making sure screws are tight to avoid any water penetration.
- Apply silicon around edge of fitting to prevent any water from getting inside to electrical connections.
- All connections must be carried out carefully, inspect all contacts before switching back on the electric circuit.

Must be installed by a licensed electrician

Contact Details: 143 Beauchamp Road Tel: 02 9381 8300 Matraville NSW 2036 Fax: 02 9666 8881 Australia Email: sales@havit.com.au Web: www.havit.com.au





