

## CAMARO CONCEPT SIDE MIRRORS

## INSTALLATION GUIDE

TOOLS: T-TAPS, SCREWDRIVER, 7MM, I OMM SOCKET, T-27 TORX BIT OPTIONAL: POWER DRILL







First, remove the tweeter cover located here.





Disconnect the tweeter harness clip located here.



Move to the bottom of the door panel and remove the (2) 7mm bolts.



Next, locate the cover inside the door handle, and remove with a flat screwdriver.



Use a T-200e park bit hite remaine this screw.





Remove this 7mm bolt. The panel is still connected to the door's harness.



Detact the door latching wire, and any plugs still connected to the panel. Locate these rubber inserts.





By the mirror, inside the door panel is where the rubber covers are located. Remove these to access the I Omm mirror bolts.





A deep socket is easier to get to these 3 bolts. If you drop the nuts inside the frame, you can remove the door speaker to retrieve them.



Disconnect the power plug from the stock mirror and pull the wires out. Feed the new mirror wires here.



T-tap into the ABL door light plug to power the concept strip. You may have to cut some housing material to expose wires.



Wire purple to white for positive Wire black to black for negative



Connect the power mirror plug located here.



Remember to replace the rubber covers, realtach any disconnected plugs, before replacing door panel



Remember:

Replace the tweeter cover

-Realtach door locking wire

Tighten down mirror bolts

-Realtach any plugs

-Fasten door panel



With everything realtached and wired you should be good to go!

If you have any questions about the install or our products please call 1-800-407-5776