SWIM HARNESS - 4 POINT

FORCE 6

Swim Harness - 4 Point

Swim Harness - 4 Point has been designed to keep the PFD in a correct position in demanding water conditions. It may save your life.

Features:

- » Includes four attachment buckles and adustable leg loops
- » Quick release buckle attachment for easy entry and egress
- » Swim Harness 4 Point will fit the following Force 6 models:
 - RescueOPS
 - Tec 2
 - R3




CARE & MAINTENANCE


- » Inspect Swim Harness 4 Point for damage often.
- » Rinse/wash by hand, and hang dry away from direct sunlight. This will increase the life of the product.
- » Store in a cool dry place away from chemicals.

Our Swim Harness - 4 Point uses Pull-the-DOT® snaps. These are heavy-duty, one-way fasteners which withstand extreme pressure from three sides without unlocking, *These snaps open and close in one direction only.

To open : Find the "DOT", and lift the snap from the side that has the "DOT"

To close: Angle snap (tang on stud first) then rock from the bottom (tang side, opposite side of the dot) to the top of the snap (DOT side). **Do not push straight down.**






How to use the Swim Harness - 4 Point

Snap the center male buckle (A) of the Swim Harness - 4 Point in the back female buckle (B) on the back of the PFD before donning.

Make sure it is the correct side out. This means the front buckles (C) will be correct side out when pulled through.

After donning th• PFD, pull the two front male buckles (C) between your legs and snap them into the two female buckles (D) attached to the front of the PFD. Make sure there are no twists.



Secure the loose end of webbing with the hook & loop T-tabs (E). This can be rolled up and fastened or fastened around the main webbing.

When you enter the water, you simply grab the two front straps on your waist, one with each hand, and then pull them both down until you feel the PFD tighten over your shoulders.

Attaching the Buckle Snaps to the PFD

