



*Stay wild.*

## USER MANUAL AMOK DRAUMR




*We suggest you get to know your  
new fantastic and nifty product before  
leaving for your first camp*




▶ Watch instead?

Check out our videos on YouTube and learn more


## 1 Find a suitable camp site



Consider the ground conditions and the trees you hang from! Avoid dead trees and branches, and spots with rocks and thorny bushes.




## 2 Straps and hammock direction



Place the strap around the tree, then pull the buckle through the loop.


The hammock has color coded corners. When lying in the hammock - green to your right, red to the left.

## 3 Inserting the buckles




The small pointed steel buckle goes through the black square buckle from the bottom. The pointed tip of the buckle must point towards the tree.

## 4 Adjusting the straps




To tighten: Pull the strap towards tree




To loosen: Pull the loop towards hammock.

## 5 Inserting the sleeping pads




Inflate your pad. If you have an Amok pad: use the included pump bag.




Put the pad inside the pad pocket, pull the sleeve over the pad, then close the zipper. **N.B. Draumr UL does not have a zipper.**

## 6 Recommended height




The hammock must not touch the ground when you enter - look out for sharp objects that can damage the fabric.




You should hang roughly 70-100 cm above the ground. The hammock will sag a bit upon entry.

## 7 Recommended angles



The rope on top of the hammock (ridgeline) should be level, and the straps at 20° to 40°.




The straps do not have to be equal length or symmetrical. One side can be higher/longer if needed.


## 8 Adjusting the hammock




Keeping your feet on the ground, sit down "halfway" to test the height and suspension straps.  
**Safety first!**



Adjust the height by lowering or raising the tree straps, or adjusting the buckles.




Avoid tightening the straps too much. Strive to get an angle between 20° and 40°.




The hammock can be moved sideways to avoid unwanted terrain features.


## 9 How to get in - alternative 1



Stand in front of the hammock, grab hold of the panels on each side.



Push the hammock down and under you while you try to sit down in the middle of the hammock.




Move one hand to the ridgeline and sit/lean back. Lift your feet inside.



Find your balance.

## How to get in - alternative 2




Stand in front of the hammock. Grab the inside panels and pull the hammock between your legs.

Push the hammock down and under you, while you try to sit down in the middle.

Move one hand to the ridgeline and sit/lean back. Lift your feet inside.

Find your balance.

## Finding your balance




Hold on to the side panels and ridgeline. Lift your body a little, and push or pull on the side panel to adjust your position

Just like riding a bike for the first time - finding your balance takes some practice!


Flat is not always level. You can slide down if you have not balanced the hammock.

Make sure you are flat AND level, before falling asleep. A common mistake is being too close to the foot end.


## 12 Chair mode




Move a little bit towards the head end, **raise your legs and pull the knee straps first - one side at a time!**



Grab the top of the panel and lift it, while pulling down on the strap handle at the same time.




Avoid leaning back and tightening both of the upper straps at the same time.




Take your weight off the back panels by sitting up straight, then tighten one strap at a time.



## 13 Insert Amok's Pole set or sticks



The pockets in the head and foot end are for sticks or the Amok pole set. Using it will lift the bug net.




Insert the pole in the foot end whilst sitting up in the hammock. Pull the foot end towards you for easier access.




If your pole doesn't fit perfectly, each end can be bent slightly. Do not bend at the middle joint.


## 14 The Bug net




You can pull the foot end towards you to make zipping easier.



Once the bug net is mounted, you can make openings where you need them, using the 3 sliders.



The ridgeline has a sliding pocket for small items. It also contains an elastic cord and cordlock.




The hook attaches to a loop in the head end. Adjust the cord lock on the ridgeline to lift the bug net.


## 15 Tips for keeping warm




A clean and dry wool baselayer and a bottle with hot water will help you stay warm.



If you put cold coffee in a thermos, it will stay cold! The same goes for you. Warm up before bed!




Glamper? Bring a reindeer hide or sheepskin!




Adding a thin foam pad on top of the inflatable pad inside the pad pocket will boost the temperature.


## Other great tips




Attach the stuff sack to the buckle inside the hammock for extra storage.




Attach a longer cord to the slider to make it easier to reach.




Open the zipper of your sleeping bag and place it in the hammock before entering.




Place your backpack near the head end to have it within reach from inside the hammock.




It is easier to enter the hammock if you tighten the knee straps halfway.



You can use the back and knee straps to adjust your sleeping position. It is not only for chair mode.




On older Draumr models without drip stoppers - using plastic clips will prevent water from running down the suspension straps.



Tarp carabiners - left image is OK in regular weather. In heavy weather, wrap the cord around itself first.







**Be prepared!** Always bring the included repair kit for the sleeping pad. Other spare parts might be useful as well.

Fold your tarp guylines like this to avoid knots and rat nests. Then attach using the velcro strap.

## 17 Some common mistakes



Tearing the fabric or breaking the pole stick by stepping into the foot end.



Hanging the hammock too high can make entering and exiting difficult, and you might hurt yourself if you fall out.