

## How to Apply?

- Clean the floor or surface well to ensure it is free of dirt and any grime
  - In case you are reapplying a fresh layer of antiskid tape, please ensure the older tape has been completely removed
- Ensure there are no cracks or breaks in the floor (chipped tiles, broken cement - water and dirt will collect here and weaken the adhesive gradually from below). Kindly get them repaired before applying this tape.
  - If you are working with tiled and wood flooring, please clean the wood thoroughly to avoid any dust settling in the grooves
- Measure the width of the step from edge to edge ideally and cut strips with scissors - this will prevent the tape from lifting off corners over time
- Release a small part of the paper strip off the back from one side and start pasting the tape from one edge of the step.
- Release the paper strip gradually as you keep pasting and pressing the tape
- Ensure the area is kept dry for at least 4-5 hours to get a good bond strength between the floor and tape

### REMEMBER

- Please apply this tape after careful consideration in areas where your family members typically walk bare feet
- While this tape can easily take the weight of heavy rollers, equipment and luggage, do check occasionally for any wear and tear in the material
- Avoid water collecting around the tape for excessive periods of time - it will impact the adhesive