




How to Fold your Bobbin Fold

Bobbin®

FOLDING YOUR BIKE

- Open the pedals like a clamshell. Mind your fingers when you open and close!
- Now you need to fold the frame.
- Flip up the safety catch (A) on the mechanism
- In the closed position, the mechanism hooks around the frame. (B)
- The hook is released with the lever (C). Pull this towards you. It may be a little stiff – that's ok – it needs to be stiff to be secure.



FOLDING YOUR BIKE (continued)

- With the mechanism open, the frame can now be folded in half
- Undo the handlebar hinge anti-clockwise and let the handlebars drop over the frame (D)
- You can lower the saddle too if you like.
- Look at the back of the bike - the magnet on the front wheel (E) can now engage with the metal plate on the rear wheel (F). This will keep the bike securely folded wheel you carry it.





- To Unfold Bike: Hook the folding mechanism around the frame, push back the lever. **IMPORTANT!** Make sure the safety catch is fully closed. If you can't close it, it's not safe to ride.
- Pull the saddle back up, fold the bars back up and tighten securely, fold the pedals down.