


**MIXX™**  
AUDIO  
WIRELESS




# **S1 WIRELESS SPEAKER**


## **QUICK START GUIDE**

# YOUR S1 SPEAKER

1. Built-in Microphone
2. Bluetooth Indicator LED
3. Bass Reflex Port



4. On/Off Switch
5. Micro USB Power Port
6. Charge Indicator LED
7. Call Answer Button



# CHARGING YOUR S1

Using the included Micro USB Charging Cable, connect the speaker to a suitable USB power source, such as a computer or mobile phone charger. The Charge Indicator LED will turn on when charging.

When the Charge Indicator LED has turned off, the speaker is fully charged.

# CONNECTING AND PAIRING

First, use the on/off switch to turn the speaker on.

Check to see if the Bluetooth Indicator LED is flashing. If it is, the speaker is in Pairing Mode and is ready to be paired with.

If the Bluetooth Indicator LED is not flashing, another device is already connected to the speaker. Press and hold

the Call Answer button to put the speaker in to Pairing Mode.

When the speaker is in Pairing Mode, search for Bluetooth devices on your phone and connect to the speaker. It will appear as 'Mixx S1'.

You will now be able to play music from your phone on the speaker.

*NOTE: If prompted for a passcode when connecting, use either '0000' or '1234'.*

# ANSWERING PHONE CALLS

If you receive a phone call while connected to the speaker, press the Call Answer button on the bottom of the speaker to accept the call.

To end the call, press the Call Answer button again. If you were playing music before the call, the music will resume.

*NOTE: Call quality may be lower or noisy when the speaker's battery is low.*

# SAFE USAGE INSTRUCTIONS

This speaker contains a Lithium battery. It must be used and charged correctly.

Improper use of this speaker may cause the battery to catch fire or explode resulting in serious or fatal injury.

The battery shall not be exposed to excessive heat such as harsh sunlight or fire.

Do not disassemble or modify the speaker  
Do not place the speaker in direct sunlight, near fires, stoves, or other high



temperature conditions.

Do not expose the speaker to water, salt water, or allow the speaker to get wet in any way.

If you dispose of the speaker, remember that it contains a Lithium battery and recycle accordingly.

For support please visit [www.mixxaudio.com](http://www.mixxaudio.com)

Made in China